



Since 1887

SI Division of  
Scientific Industries, Inc.



# Instruction Manual: TORBAL FORCE GAUGES FB Precision & FC Precision PRO Series

## Table of Contents

Chapter 1: Cautionary Notes and Warnings .....	2
Chapter 2: Specifications .....	5
Chapter 3: Parts Description .....	8
Chapter 4: Keys, Display Indicators and Commands .....	10
Chapter 5: Modes and Function Descriptions.....	11
Chapter 6: Unpacking the Force Gauge and Getting Started.....	13
Chapter 7: Taking Measurements and Saving Results .....	15
Chapter 8: Main Menu .....	19
Chapter 9: Applications and Modes.....	20
9.1 Standard Mode .....	20
9.2 Peak Mode .....	22
9.3 Multi Peak Mode .....	24
9.4 Fill Meter.....	26
Chapter 10: Data Manager – Retrieving and Managing Saved Data.....	28
10.1 Retrieving and Managing Saved Data .....	29
10.2 Custom data file name format.....	30
10.3 Formatting the SD card .....	31
Chapter 11: Measurement Settings.....	32
11.1 Record and Speed .....	32
11.2 Units – Selecting Default Unit of Measure .....	34
11.3 Auto Zeroing .....	35
11.4 Threshold .....	36
11.5 Direction – Reversing Compression and Tension .....	37
Chapter 12: Configuration .....	38
12.1 Printout.....	39
12.2 Gauge Change (FC Models Only) .....	40
12.3 Interface(USB, RS232, wireless).....	41
12.4 LCD Settings .....	42
12.5 Time & Date .....	43
12.6 Keypad-Disabling and Enabling Buzzer Feedback.....	44
12.7 Auto-Off – Power Save Settings.....	44
12.8 Battery- Disabling Charging .....	45
12.9 External Input- Remote Trigger (FC Models Only).....	46
12.10 Firmware Update .....	47
12.11 Defaults.....	48
Chapter 13: Calibration.....	49
13.1 Calibrating with Mass or Force .....	48
13.2 Setting Gravitational Acceleration Value .....	52
13.3 Using Geographical Location Coordinates .....	52
13.4 Setting a Correction Value .....	53
13.5 Setting Load Cell Sensitivity mV/V (Use when interchanging load-cells) .....	54
13.6 Restoring Factory Calibration .....	54
13.7 Calibration PIN Access .....	55
Chapter 14: Force Gauge Info .....	56
Chapter 15: Interchanging Load-Cells(FC1k-FC50k Models Only).....	57
15.1 Adding New Load-Cells .....	56
15.2 Restoring Factory Calibration .....	58
Chapter 16: Connecting to PC - Communication Protocol.....	60
16.1 Force Gauge Communication Protocol.....	62




---

Chapter 17: Wireless PC Connection (FC Models Only) .....	63
Chapter 18: Input/Output Port Configuration (FC Models Only).....	67
Chapter 19: Common Errors and Troubleshooting .....	68
Chapter 20: Maintenance .....	69
Chapter 21: Accessories .....	70
Chapter 22: Replacement Parts .....	71
Chapter 23: Technical Information, Measurement and Dimensions.....	72
Chapter 24: Limited Warranty .....	82


# Chapter 1: Cautionary Notes and Warnings

## Important Handling Cautions and Warnings


Always handle your force gauge with care.  
 Damage caused by improper handling is not covered under warranty.




**DO NOT** let the force gauge fall or drop onto the ground!






**Never** use the force gauge if there is an object or material wedged between the measuring rod and frame!



**DO NOT** pass or handle liquids near the force gauge to prevent spillage and liquid damage!




**Always** align the force gauge shaft to the object measured, to prevent the shaft from warping and damaging the device!




**DO NOT** attempt to measure the force of an object that is submerged in a liquid


**Cautionary Notes and Precautions**




**Never stand under a force gauge in use. Equipment may fall or collapse, causing breakage and possible injury.**




**Keep safe distance from the load cell. Always use safety gloves, safety glasses and other protective gear.**



**Always keep the force gauge and the power supply from water or other liquids.**



**Damaged batteries must be handled with extra care. Use rubber gloves and safety glasses. Dispose only in designated recycling centers.**



**Always disable charging before installing disposable batteries. Charging non-rechargeable, alkaline batteries can be hazardous and cause damage to the force gauge.**

**CAUTION:**



- The force gauge is designed for indoor use only.
- Do not operate the force gauge in hazardous areas or under dangerous conditions.
- Do not use the force gauge in locations subject to high humidity or dust.
- Do not connect cables in ways other than those mentioned in this manual.
- Never stand on or lean on this product. Equipment may fall or collapse, causing breakage and possible injury.
- Before moving the product, unplug it and unplug all cables connected to it.
- When storing, transporting or returning the force gauge for service, always use the original packaging.

**WARNING:**



- Never attempt to repair, disassemble or modify the force gauge. Tampering with the force gauge may result in injury and cause greater damage to the equipment.
- Be sure to use the specified power source.
- Do not allow foreign matter to fall onto the force gauge.
- If water or other liquid spills onto the force gauge, unplug the power cord immediately and contact technical support.



- Disposal of electronic equipment in waste containers is forbidden by law.


## Important Mounting and Installation Cautions



- Force Gauge Capacity and swivel bearing joint must always exceed the predicted measurement load.
- Elements or parts used in mounting that are not supplied with the force gauge, such as a shackle, rope, chain, nut or a bolt, must withstand force of no less than 150% of force gauge capacity.

### Warning!


Mounting bolts and other connection hardware, parts, or elements not supplied with the force gauge must sustain loads of at least 150% of force gauge capacity. Any bolt or nut must be precisely matched to the diameter of the swivel bearing joint with tolerance of at least 0.5mm. Swivel bearing joints must be protected against rapid movements and secured with pads against slips.






## Chapter 2: Specifications

### FB5 - FB500


	Model					
	FB5	FB10	FB20	FB50	FB200	FB500
Capacity	1lb   0.5kgf   5N	2lb   1kgf   10N	4lb   2kgf   20N	10lb   5kgf   50N	40lb   20kgf   200N	100lb   50kgf   500N
Resolution	0.0002lb   0.1gf   0.001N	0.0005lb   0.2gf   0.002N	0.001lb   0.5gf   0.005N	0.002lb   1gf   0.01N	0.01lb   5gf   0.05N	0.02lb   10gf   0.1N
Sampling Rate	80Hz					
Accuracy	± 0.2% Full Scale					
Overload	200% Full Scale (Display Limit: 110%)					
Interface	USB (B Type), RS232, microSD (SDHC Class 4)					
Input / Output Port	-					
Operating Temperature	14°F to 104°F   -10 to 40°C   Humidity: Up to 80 % Max.					
Measuring Units	N, kgF, lbF, ozF, lb, oz, kg					
Rechargeable Batteries	4 x Ni-MH 2700mAh					
Battery Operating Time	32h (LCD Backlight OFF)   27h (LCD Backlight ON)					
Power Supply	12V, 1.2A					
Shaft Size	0.43"   11mm (thread M6x8mm)					
Dimensions	8.46" x 3.93" x 1.57"   215mm x 100mm x 40mm					
Unit Weight	1.2lb (560g)					

### FB1k – FB50k


	Model					
	FB1k	FB2k	FB5k	FB10k	FB20k	FB50k
Capacity	200lb   100kgf   1kN	400lb   200kgf   2kN	1,000lb   500kgf   5kN	2,000lb   1t   10kN	4,000lb   2t   20kN	10,000lb   5t   50 kN
Resolution	0.05lb   20gf   0.2N	0.1lb   50gf   0.5 N	0.2lb   100gf   1N	0.5lb   200gf   2N	1lb   500gf   5N	2lb   1kgf   10N
Sampling Rate	80Hz					
Accuracy	± 0.2% Full Scale					
Overload	200% Full Scale (Display Limit: 110%)					
Interface	USB (B Type), RS232, microSD (SDHC Class 4)					
Input / Output Port	-					
Operating Temperature	14°F to 104°F   -10 to 40°C   Humidity: Up to 80 % Max.					
Measuring Units	N, kgF, lbF, ozF, lb, oz, kg					
Rechargeable Batteries	4 x Ni-MH 2700mAh					
Battery Operating Time	32h (LCD Backlight OFF)   27h (LCD Backlight ON)					
Power Supply	12V, 1.2A					
Sensor Cable Length	9.5ft					
Indicator Dimensions	8.46" x 3.93" x 1.57"   215mm x 100mm x 40mm (not including load-cell)					
Indicator Weight	1lb (415g) not including load-cell					



**FC5 - FC500**

	Model					
	FC5	FC10	FC20	FC50	FC200	FC500
Capacity	1lbF   0.5kgf   5N	2lbF   1kgf   10N	4lbF   2kgf   20N	10lbF   5kgf   50N	40lbF   20kgf   200N	100lbF   50kgf   500N
Resolution	0.0002lbF   0.1gf   0.001N	0.0005lbF   0.2gf   0.002N	0.001lbF   0.5gf   0.005N	0.002lbF   1gf   0.01N	0.01lbF   5gf   0.05N	0.02 lbF   10gf   0.1N
Sampling Rate	1000Hz					
Accuracy	± 0.1% Full Scale					
Overload	200% Full Scale (Display Limit: 110%)					
Interface	BT Wireless, USB (B Type), RS232, microSD (SDHC Class 4)					
Input / Output Port	YES (THR)					
Operating Temperature	14°F to 104°F   -10 to 40°C   Humidity: Up to 80 % Max.					
Measuring Units	N, kgF, lbF, ozF, lb, oz, kg					
Rechargeable Batteries	4 x Ni-MH 2700mAh					
Battery Operating Time	29h (LCD Backlight OFF, BT Wireless OFF)   25h (LCD Backlight ON, BT Wireless OFF)					
Power Supply	12V, 1.2A					
Shaft Size	0.43"   11mm (thread M6x8mm)					
Dimensions	8.46" x 3.93" x 1.57"   215mm x 100mm x 40mm					
Unit Weight	1.2lb (560g)					


**FC1k – FC50k**

	Model					
	FC1k	FC2k	FC5k	FC10k	FC20k	FC50k
Capacity	200lbF   100kgf   1kN	400lbF   200kgf   2kN	1,000lbF   500kgf   5kN	2,000lbF   1t   10kN	4,000lbF   2t   20kN	10,000lbF   5t   50 kN
Resolution	0.05lbF   20gf   0.2N	0.1lbF   50gf   0.5 N	0.2lbF   100gf   1N	0.5   200gf   2N	1lbF   500gf   5N	2lbF   1kgf   10N
Sampling Rate	1000Hz					
Accuracy	± 0.1% Full Scale					
Overload	200% Full Scale (Display Limit: 110%)					
Interface	BT Wireless, USB (B Type), RS232, microSD (SDHC Class 4)					
Input / Output Port	YES (THR)					
Operating Temperature	14°F to 104°F   -10 to 40°C   Humidity: Up to 80 % Max.					
Measuring Units	N, kgF, lbF, ozF, lb, oz, kg					
Rechargeable Batteries	4 x Ni-MH 2700mAh					
Battery Operating Time	29h (LCD Backlight OFF, BT Wireless OFF)   25h (LCD Backlight ON, BT Wireless OFF)					
Power Supply	12V, 1.2A					
Sensor Cable Length	9.5ft					
Indicator Dimensions	8.46" x 3.93" x 1.57"   215mm x 100mm x 40mm (not including load-cell)					
Indicator Weight	1lb (415g) not including load-cell					









**FC100k – FC200k Super Load PRO**

	Model		
	FC100k	FC150k	FC200k
Capacity	22,000lbf   10t   100kN	33,000lbf   15t   150kN	44,000lbf   20t   200kN
Resolution	5lbf   2kgf   20N	10lbf   5kgf   50N	10lbf   5kgf   50N
Sampling Rate	1000Hz		
Accuracy	± 0.1% Full Scale		
Overload	200% Full Scale (Display Limit: 110%)		
Interface	BT Wireless, USB (B Type), RS232, microSD (SDHC Class 4)		
Input / Output Port	YES (THR)		
Operating Temperature	14°F to 104°F   -10 to 40°C   Humidity: Up to 80 % Max.		
Measuring Units	kN, kgF, lbf, ozF, lb, oz, kg		
Rechargeable Batteries	4 x Ni-MH 2700mAh, 1.2V		
Battery Operating Time	16h (LCD Backlight OFF, BT Wireless OFF)   13h (LCD Backlight ON, BT Wireless OFF)   Min 10h (LCD Backlight ON, BT Wireless ON)		
Power Supply	12V, 1.2A		
Indicator Dimensions	8.46" x 3.93" x 1.57"   215mm x 100mm x 40mm (not including load-cell)		
Indicator Weight	1lb (415g) not including load-cell		

# Chapter 3: Parts Description




**Tips and Attachments** (Included only with high resolution and high precision models FB/C5 to FB/C500)



	<b>Attachment Name</b>	<b>Application</b>
A	Flathead	Surface pressure force
B	Cone Point	Point pressure force
C	V-Groove	Pressure force on an axis or edge
D	Chisel Point	Edge pressure force
E	Hook	Pull force or hanging an object
F	Shaft Extension	Extension to tips and attachments



## Chapter 4: Keys, Display Indicators and Commands



Key	Primary Function	Secondary Function
ON / OFF	Turn the unit ON	Turn the unit OFF
UNIT / CLEAR	Toggle between available units of measure. Exit menu folder	Press once to pause measuring sequence. Press and hold to reset measuring sequence before time is reached.
BACKLIGHT	Turn the backlight on	
FUNCTION	Toggle between enabled application modes	Navigation key UP. Press and hold to access Statistical Analysis at any time
START	Start measuring sequence or capture measurement	Navigation key Left.
PRINT	Initiate print or data transfer via RS232 or USB	Navigation key Right
MENU	Access the Main Menu. Press once to access Menu options	Navigation key down. In Peak Mode press and hold to toggle between Tension, Compression, Tension & Compression
ENTER	Zero the Force Gauge	Accept and confirm commands
Display Indicator	Description	
OFF	Power Off	The force gauge is turned OFF and in standby mode.
AUT	Auto-Zero Setting	Auto zeroing enabled and the force gauge maintains a “center of zero” condition within.
SDH	MicroSD Card	The MicroSD Card is inserted and functional
MAN	Manual	Standard or Peak Modes are set to Manual
LOCK	Result Lock	Result is locked on the screen until cleared.
PK	Peak	Peak Mode enabled
ACQ	Acquiring	Force Gauge is acquiring measurements
TRG	Trigger	Trigger value has not been reached
DELAY	Delay	Delay in progress
MIN	Minimum	Indicates that the minimum threshold limit has been reached
MAX	Maximum	Indicates that the maximum threshold limit has been reached
OK	Target	Indicates that the target threshold limit has been reached
	Stability Indicator	The result has stabilized and reading may be taken.
	Wireless	Wireless data transmitter is enabled
	Battery	Battery Charging Status

## Chapter 5: Modes and Function Description

### Standard Mode [Menu>Applications>Standard Mode]

The standard mode offer utmost flexibility when using the force gauge manually, in a test stand, or while connected to a PC. Force measurements can be captured manually with a press of the start button or automatically over a specified time frame. The mode is equipped with Time Delay, Trigger, and Threshold features.

---

### Peak Mode [Menu>Applications>Peak Mode]

The peak mode automatically detects the maximum force measured during a test. The feature pinpoints the exact force applied to an object before it gives or breaks under pressure. The application can be configured to detect force automatically or manually.

---

### Multi-Peak Mode [Menu>Applications>Multi Peak]

The Multi-Peak mode records multiple peaks detected during a user specified time frame. The feature detects unlimited number of peaks in a measured sequence. The Multi-Peak mode is particularly useful when measuring force of objects that do not instantly give or break under pressure, such as fabrics or flexible materials.

---

### Fill Meter [Menu>Applications>Fill Meter]

Filling meter indicator can be activated in conjunction with any mode of the force gauge. The fill meter is a digital non-linear pie meter which has greatly increased sensitivity at the set capacity cutoff point. The feature allows to set a custom cut off point that is suitable to the application. This feature helps to avoid exceeding the maximum capacity of the force by providing visual feedback while taking measurements.

---

### Programmable Thresholds Monitoring [Menu>Applications>Mode>Threshold]

Programmable threshold limits are available in all force gauge modes. The feature allows to set minimum, maximum, and target values that are monitored by the force gauge. When exceeded the displays MIN, MAX, and OK indicators are on the display. Each indicator can be set to sound a single or a continuous alarm. Threshold values are also used to determine if the force applied during tests can produce consistent results that stays within the set parameters.

---

### Peak Detection / Peak Sensitivity [Menu>Applications>Peak Mode>Peak Detec.]

Peak and Multi-Peak modes are equipped with a sensitivity detection feature which allows to disregard unwanted peak measurements that may be caused by shakes or vibration. The peak sensitivity detection feature allows peak detection modes to be fine-tuned to a specific application.

---

### Data Manager [Menu>Data Manager]

The data manager feature allows to quickly review and retrieve saved measurements. The feature organizes data into function folders with chronological .txt file names. File names can be assigned with a unique alphanumeric names or identifier, which are automatically organized chronologically.

---

---

**Auto-Save / Automatic Data Storing [Menu>Data Manager>Auto-Save]**

Auto-save automatically saves results and statistical analysis of the measurements to the MicroSD card. When enabled the force gauge will save results at the end of each measurements. Each result set is assigned with unique file name.

---

**Record & Speed / Configurable Sampling Speed [Menu>Measur. Settings>Record & Speed]**

The gauge can be set to measure force at a desired speed. A slower rate makes it easier for the force measurements to be seen on the display in real-time. A faster measuring speed allows for a more accurate test as the force gauge can capture more results in a shorter time sequence, and samples are taken more frequently.

---

**Printout / Configurable Receipt Printing [Menu>Configuration>Printout]**

The force gauge can send results directly to a printer as well as third party software such as MS excel or notepad. The printed information can be configured to include the date, time, measurement name, user ID, signature line, and a series of customizable notes.

---

**External Input / Output and Input Modes (FC Models only) [Menu>Configuration>External Input]**

The threshold output mode enables the Output port by sending voltage level signals which can be used for signaling or controlling external peripherals that can connect with the force gauge. The output mode can be used in combination with Programmable Thresholds Monitoring. Input mode allows an external button or a pedal to be used as trigger for starting force measurements and taking samples. OUTPUT Ampacity: I max=25mA / U nom=24V (open collector type, emitters connected– GND) | INPUT Voltage Range IN (+)/IN (-): U in=12-18V / I in max=50Ma

---


**Gauge Change / Interchangeable load-cell (1Kn to 50KN | FC Models Only) [Menu>Configuration>Gauge Change]**

Gauge Change allows to use multiple external loadcells with one force gauge indicator. Switching between load-cells is easily done through the force gauge menu with minimum configuration or setup. The Gauge Type feature allows to store up to 16 external load cells. The feature is ideal for applications that require multiple result resolutions and capacities.


---

# Chapter 6: Unpacking the Force Gauge and Getting Started




1. Carefully take the force gauge out of the case.
2. Select a suitable tip to effectively conduct a measurement. Choose the tip that will best measure the force of the object to be tested.
3. Slowly screw the tip onto the measuring shaft at the top of the force gauge.



4. High capacity force gauges with an external load cells require the use of swivel bearing joint. Firmly screw in the swivel bearing joints into the load cell.




5. If necessary, connect the force gauge to a power outlet by plugging the AC adapter into the 12V socket at the bottom of the unit. Once the AC adapter is connected to the force gauge, plug the other end into a wall socket.
  
6. To assure optimum precision and stability of the measurement, the force gauge should be mounted on a test stand. To mount the force gauge, use the four threaded holes located in the rear of the housing.






# Chapter 7: Taking Measurements and Saving Results


1. Press the *ON/OFF* key to turn the force gauge ON.




2. Do not move or attempt to use the force gauge as it is initializing. The force gauge will power on in the last mode it was turned off.
3. Once the force gauge is turned on, it is ready to use.




4. To select or change a mode press the Function key until a desired mode is highlighted. Only enabled modes are available for selection.




- To select or change a unit of measure press the Unit / Clear button until a desired unit of measure is highlighted.




- Before taking a measurement zero the force gauge by pressing the →0← / ENTER key.




- To measure the compression force (push) of an object, align the force gauge shaft to the object measured. If measuring by hand grasp the device firmly. Push the force gauge forward with the attached tip pressing into the object. Observe the measurements recorded as the force is applied.



- To measure the tension force (pull) of an object, align the force gauge shaft to the object measured. If measuring by hand grasp the device firmly. Wrap the hook tip around the object and pull the force gauge away from the object. Observe the measurements being recorded as the force is applied.



9. Depending on the configuration and mode in use, measurements are captured automatically or with a press of the START key.



10. To pause measurements, press the Unit / Clear key once. TO clear and rest the measurement at any time press and hold the Unit / Clear key.
11. Once the measurement time has expired, or all required samples have been captured, the force gauge will conduct a statistical analysis which is automatically displayed on the screen. Use the arrow keys to select and view the chart and histogram. To clear data and start new measurement select EXIT.

**PEAK MODE STATUS**

Status:	Successful
Samples:	10
Total:	+ 17.10 N
Average:	+ 5.70 N
MAX:	+ 7.25 N
MIN:	+ 4.80 N
MAX-MIN:	+ 2.45 N
St. dev:	1.65 N
Rel. dev:	23.65 %

**Save** Exit Chart Histo

**HISTOGRAM**

MIN MAX

< L01 = 1 >


PEA00001: + 7.25 N

**RESET DATA**

Please confirm:

NO  
**YES**



12. To save the result to your MicroSD card select *SAVE* and press the enter key. To save data to a new file select `<set file name>` or chose a previously saved file to overwrite data.





# Chapter 8: Main Menu

The *Main Menu* is used to configure the force gauge and its measuring modes. There are nine options within the Main Menu:

1. To access the USER MENU, press the *MENU* key.



2. Use the arrow keys to scroll through the options and press ENTER to select one. *EXIT* will always return to the previous screen or menu folder.



# Chapter 9: Applications and Modes

- To enable and configure the application modes press the Menu key to enter the Main Menu. Use the navigation keys to select Applications and press the Enter key.

**USER MENU**

1. Applications
2. Data Manager
3. Measur. Settings
4. Configuration
5. Calibration
6. Info
7. Exit

## 9.1 Standard Mode

- To configure the Standard Mode use the navigation keys to select “Standard Mode” in “Applications” folder and press ENTER.

**APPLICATIONS**

1. Standard Mode
2. Peak Mode
3. Multi Peak
4. Fill Meter
5. Exit

- The status and available options will be displayed. If the function is currently in use the status will be set to “Enabled”. Use the arrow keys to navigate through the features and configure the mode.

**STANDARD MODE**


1. Status: <Enabled> <Disabled>
2. Mode: <Auto> <Manual>
3. Delay <Trigger> <Start>
4. Trigger: 0.00N
5. Del. Time: 0.0s
6. Meas. Time: 60.0s | Quantity: 10
7. Threshold: <ON> <OFF>
8. Min: 0.00N
9. Target: 0.00N
10. Max: 0.00N
11. Exit




### Standard Mode Configuration Features

Feature	Options	Description and Functionality
Status	<Enable, Disable>	Enables and Disables the standard mode from the function menu. When disabled feature is not available for selection while pressing the function key.
Mode	<Auto, Manual>	<b>Manual:</b> Measurements are captured with the press of the start key. Measurement sequence is based on the quantity parameter set in the Quantity field. <b>Auto:</b> Measurements are automatically captured over specified period which is based on the measurement time parameters. Pressing the start key initiates the measurement cycle. The feature utilizes Delay and Trigger settings.
Delay	<Start, Trigger>	<b>Start:</b> Force trigger is disabled. The measurement sequence initiates after press of the Start key. Measurement sequence begins once the Delay Time value is reached. <b>Trigger:</b> Both Trigger and Delay Time values must be reached before measurement sequence begins.
Trigger	custom value	The amount of Force that needs to be reached before the measurement sequence begins. (Auto only)
Del. Time	custom value	The time that must be reached before the measurement sequence begins. (Auto only)
Quantity	custom value	Number of measurements that must be captured to end the measurement cycle. (Manual Only)
Meas. Time	custom value	Total time of the measurement sequence in the automatic mode.
Threshold	<On, Off>	Enables and disables measurement threshold monitoring.
Min	custom value	Minimum threshold value. When reached, MIN is displayed.
Target	custom value	Target threshold value when reached OK, is displayed.
Max	custom value	Maximum threshold value. When reached, and exceeded MAX is displayed
Exit		Exits the Applications settings folder.

- To begin measurement, align the force gauge shaft to the object measured. If measuring by hand grasp the device firmly. For compression push the force gauge forward with the attached tip pressing into the object. For tension wrap the hook tip around the object and pull the force gauge away from the object.





- Use the START key to begin acquiring force measurements in the Automatic mode or to capture single measurement in the manual mode.





- Once the measurement time is reached (Automatic), or all required samples have been captured (Manual), the force gauge will conduct a statistical analysis which is automatically displayed on the screen.

## 9.2 Peak Mode

- To configure the Peak Mode use the navigation keys to select “Peak Mode” in “Applications” folder and press ENTER.



- The status and available options will be displayed. If the function is currently in use the status will be set to “Enabled”. Use the arrow keys to navigate through the features and configure the mode.










### Peak Mode Configuration Features

Feature	Options	Description and Functionality
Status	<Enable, Disable>	Enables and Disables the Peak mode from the function menu. When disabled feature is not available for selection while pressing the function key.
Mode	<Auto, Manual>	<b>Manual:</b> Peak force is automatically detected and displayed on the Force Gauge. START key must be pressed to store the display peak value. The force gauge must be manually zeroed before next measurement by pressing the →0← ENTER key. Measurement sequence is based on the quantity parameter set in the Quantity field. Trigger value must be reached before peak force is detected. Peak forces below the trigger value are disregarded. <b>Auto:</b> The peak force is automatically detected and displayed on the Force Gauge. The result is automatically stored. The Force Gauge is automatically zeroed before the next measurement. Auto utilizes peak detection and auto reset parameters.
Quantity:	custom value	Number of measurements that must be captured to end the measurement cycle.
Trigger	custom value	The amount of Force that needs to be reached before the measurement sequence begins.
Peak Detec.	custom value	Allows to disregard unwanted peaks and sets peak sensitivity detection. Peak values are stored only if the detected peak is followed by a set percentage drop defined by the Peak Detection parameter.
Auto Reset	<1s, 3s, 5s, 10s, 30s>	The time the peak value is displayed on the screen before automatically zeroing.
Threshold	<On, Off>	Enables and disables measurement threshold monitoring.
Min	custom value	Minimum threshold value. When reached, MIN is displayed.
Target	custom value	Target threshold value when reached OK is displayed.
Max	custom value	Maximum threshold value. When reached, and exceeded MAX is displayed.
Exit		Exits the Applications settings folder.

- To capture a Peak force, align the force gauge shaft to the object measured. If measuring by hand grasp the device firmly. For compression push the force gauge forward with the attached tip pressing into the object. For tension, wrap the hook tip around the object and pull the force gauge away from the object.





- The peak of the force will be automatically detected and displayed on the force gauge. If set to automatic, the peak will be automatically captured and the force gauge will automatically zero for the next reading. If set to the Manual mode, press the START key to capture the detected peak which is displayed on the force gauge. Prior to taking the next reading zero the gauge by pressing the →0← ENTER key. To switch between Compression and Tension press and hold the Menu key. To print the result or send it to a PC, press the Print key.



- Once the required samples have been captured, the force gauge will conduct a statistical analysis which is automatically displayed on the screen.


### 9.3 Multi-Peak Mode

- To configure the Multi-Peak Mode use, the navigation keys to select “Multi Peak” in “Applications” folder and press ENTER.



2. The status and available options will be displayed. If the function is currently in use the status will be set to “Enabled”. Use the arrow keys to navigate through the features and configure the mode.


MULTI PEAK	
1. Status:	<Enabled> <Disabled>
2. Delay	<Trigger> <Start>
3. Peak Detec.:	5%
4. Trigger:	0.00N
5. Del. Time:	0.0s
6. Meas. Time:	60.0s
7. Threshold:	<ON> <OFF>
8. Min:	0.00N
9. Target:	0.00N
10. Max:	0.00N
11. Exit	




### Multi Peak Mode Configuration Features

Feature	Options	Description and Functionality
Status	<Enable, Disable>	Enables and Disables the Multi Peak mode from the function menu. When disabled feature is not available for selection while pressing the function key.
Delay	<Start, Trigger>	<b>Start:</b> Force trigger is disabled. The measurement sequence initiates after press of the Start key. Measurement sequence begins once the Delay Time value is reached. <b>Trigger:</b> Both Trigger and Delay Time values must be reached before measurement sequence begins.
Peak Detec.	custom value	Allows to disregard unwanted peaks and sets peak sensitivity detection. Peak values are stored only if the detected peak is followed by a set percentage drop defined by the Peak Detection parameter.
Trigger	custom value	The amount of Force that needs to be reached before the measurement sequence begins.
Del. Time	custom value	The time that must be reached before the measurement sequence begins.
Meas. Time	custom value	Total time of the measurement sequence.
Threshold	<On, Off>	Enables and disables measurement threshold monitoring.
Min	custom value	Minimum threshold value. When reached, MIN is displayed.
Target	custom value	Target threshold value when reached OK is displayed.
Max	custom value	Maximum threshold value. When reached, and exceeded MAX is displayed.
Exit		Exits the Applications settings folder.

- To begin measurement, align the force gauge shaft to the object measured. If measuring by hand grasp the device firmly. For compression push the force gauge forward with the attached tip pressing into the object. For tension wrap the hook tip around the object and pull the force gauge away from the object.





- Use the START key to begin acquiring force measurements.





- Once the measurement time is reached, the force gauge will conduct a statistical analysis which is automatically displayed on the screen.

### 9.4 Fill Meter


- To enable the Fill Meter use the navigation keys to select Fill Meter in Applications folder and press ENTER.



- Use the navigation keys to select Status press the Enter key and change the status to Enabled.




- Use the navigation keys to select Range and press the Enter key to change the range value of the Fill Meter. The range value defines the full scale of the Fill Meter. When enabled the Fill Meter is visible in all application modes.




# Chapter 10: Data Manager - Retrieving and Managing Saved Data

Data Manager allows to view and manage saved data, enables automatic saving of measurement data, as well as file format configuration and SD card formatting.

1. To access Data Manager, press the Menu key and access the Main Menu. Use the navigation keys to select Data Manager and press the Enter key



2. Use the arrow keys to navigate through the features and configure the function.





### Data Manager Configuration Features



Feature	Options	Description and Functionality
Auto-Save	<Off, On>	Results are automatically saved at the end of each measurement sequence.
SD Card	-	Allows to define custom folder and file name. Which is used when saving data to the SD card.
SD Format	-	Formats and deletes all data stored on the SD card.

## 10.1 Retrieving and Managing Saved Data



- To view and manage saved data, select View/ Managed Saved from the Data Manager Menu and press the Enter key.




- Data is sorted into corresponding applications Mode. Use the navigation keys to select the mode and view saved data.



- Use the navigation keys to select a saved data file and press the Enter key. Select Load to view the file or permanently delete the file from the SD card.




4. Statistical analysis will be automatically displayed on the screen. Use the arrow keys to select and view the chart and histogram.




## 10.2 Custom data file name format

1. To customize the data file name format, select SD Card from the Data Manager menu and press the Enter key.



2. To assign a custom name of the folder for saving measurement results, select Folder and press the Enter key. Use the navigation keys to key in the folder name. The folder name cannot exceed 7 characters. Press Enter to confirm. The folder name will be created on the SD card.





3. To assign custom file name for each measurement set, select File and press the Enter key. Use the navigation keys to key in the file name. The file name cannot exceed 7 characters. The last three characters must be numeric. Press Enter to confirm. Each file name automatically increments the last numeric value.





### 10.3 Formatting the SD card

1. To format and delete stored data on your micro SD card, select SD Format from the Data Manager menu and press the Enter key.



2. Select OK to format the SD card. Warning: All Records will be deleted!



# Chapter 11: Measurement Settings

- To access the Measurement Settings menu, press the Menu key, select Measur. Settings and press the Enter key.

**USER MENU**

1. Applications
2. Data Manager
3. Measur. Settings
4. Configuration
5. Calibration
6. Info
7. Exit

**MEASUR. SETTINGS**

1. Record & Speed
2. Units
3. Auto Zeroing
4. Threshold
5. Direction
6. Exit

- Use the arrow keys to navigate through the features and configure the function.

**MEASUR. SETTINGS**

1. Record & Speed
2. Units
3. Auto Zeroing
4. Threshold
5. Direction
6. Exit

## 11.1 Record & Speed


- To change the force gauge capturing speed and measurement record format, select Record & Speed from the Measurement Settings menu and press the Enter key.

**MEASUR. SETTINGS**

1. Record & Speed
2. Units
3. Auto Zeroing
4. Threshold
5. Direction
6. Exit

- To configure the force gauge speed at which measurements are captured select Speed and press the Enter key. Use the navigation keys to key in a desired speed rate. Higher capture speed decreases the maximum Sampling Time and Total number of measurements that can be captured in a sequence.

RECORD & SPEED	
1. Speed:	0.001 s
2. Record	< R/-, R/D & T >
3. Exit	
Hz = 1000	
Samp. Time = 71.9 s	
MaxSamp. = 71936	




### Speed Settings

	Maximum Speed	Minimum Speed
<b>FB Models</b>	0.0125 s	100.000 s
<b>FC Models</b>	0.0010 s	100.000 s

- To change the record format of captured measurements, use the navigation keys to select Record and press the Enter key.

RECORD & SPEED	
1. Speed:	0.001 s
2. Record:	< R/-, R/D&T >
3. Exit	
Hz = 1000	
Samp. Time = 71.9 s	
MaxSamp. = 71936	





### Measurement Record Format Settings

<b>R/-</b>	Captured measurement does not include date and time stamping
<b>R/D &amp; T</b>	Each captured measurement is stamped with date and time.



- Hertz, Sampling Time, and Maximum number measurements are automatically recalculated after the Speed and Record parameters are changed.

## 11.2 Units – Selecting default unit of measure

1. To select a force gauge default unit of measure, select Units from the Measurement Settings menu and press the Enter key.





2. To select a default unit of measure, use the navigation keys to select a desired unit and press the Enter key to place a checkmark corresponding to the unit.





### 11.3 Auto Zeroing



1. To adjust the Auto-Zero select Auto Zeroing from the Measurement Settings menu and press the Enter key. Auto Zeroing automatically maintains zero of the force gauge, if the load cell is not affected by any external force or if the zero was set by pressing the →0← key.



2. To disable or enable Auto Zeroing, use the navigation keys to select Status and press the Enter key.





3. To change the Auto Zeroing range, use the navigation keys to select Range and press the Enter key. Key in an autozeroing value between 1d and 100d.





## 11.4 Threshold – Output Port and Internal Buzzer



1. To enable the Threshold Output port and buzzer signaling for threshold limits, select Threshold from the Measurement Settings menu and press the Enter key.



2. To enable the output port, use the navigation keys to select Status and press the Enter key.



3. To enable and configure buzzer signaling, use the navigation keys to select a threshold limit and press the enter key.





### Threshold Limit Buzzer Settings



<b>Single</b>	Buzzer sounds once when the limit is reached
<b>Continuous</b>	Buzzer makes a continuous sound when the limit is reached

## 11.5 Direction – Reversing Compression and Tension

- To reverse the direction between tension and compression, select Direction from the Measurement Settings menu and press the Enter key.




- Use the navigation keys to select Status and press the Enter key.




<b>Normal</b>	compression force push is positive ( + )   tensions force pull is negative ( - )
<b>Reverse</b>	compression force push is negative ( - )   tensions force pull is positive ( + )

# Chapter 12: Configuration


- To access the Configuration menu, press the Menu key, select configuration and press the Enter key.



USER MENU
1. Applications
2. Data Manager
3. Measur. Settings
<b>4. Configuration</b>
5. Calibration
6. Info
7. Exit



- Use the arrow keys to navigate through the features and configure the function.





CONFIGURATION
1. Printout
2. Gauge Change
2. Interface
3. LCD Settings
4. Time & Date
5. Keypad
6. Auto-Off
7. Battery
8. External Input
9. Firmware Update
10. Defaults
11. Exit





## 12.1 Printout

1. To configure printing parameters and print details select Print from the Configuration menu and press the Enter key



2. To enable or disable printable parameters use the navigation keys to select a desired parameter and press the Enter key to place or remove a checkmark corresponding to the parameter. Disabled parameters will not appear on the receipt printout and will not be transited via interface ports.





3. To key in printable custom notes, select a Note slot and press the right arrow key. Use the arrow key to select characters and input notes. Use the Enter key to save.



<b>Header</b>	Force Gauge Model and Serial Number
<b>Date</b>	Current Date
<b>Time</b>	Current Time
<b>Note 1, 2, 3</b>	Custom Notes and Remarks
<b>Number</b>	Printout Number
<b>Signature</b>	Signature Line

## 12.2 Gauge Change (FC Models Only)

1. To enable load-cell interchange feature on external FC force gauges, select Gauge Change and press the Enter key.





2. Use the navigation keys to select Status and press enter. Change the status to enable. The Gauge Type feature setup and list will be enviable in the Main Menu.





## 12.3 Interface (RS232, USB, Wireless)

1. To configure baudrates and other PC interface parameters, select Interface from the configuration menu and press the Enter key



2. Select a desired port and press the Enter key. Use the navigation keys to select port parameters and press the Enter key to save the settings. To change the transmission data format mode select Sending and choose a desired sending mode.



### Transmission data format mode

Normal	Stable Result Required	Stable weighing result is required before data is sent
No STB	No Stability Required	Result is sent as soon as the transfer data button is pressed. Force Gauge does not wait for a stable result
Auto STB	Automatic	Weighing result is automatically transferred from the force gauge after it stabilizes (no push key required)
Remove	Remove All Characters	All none force result characters are removed. Force gauge sends only numeric values. Date, Time, Unit of measure are removed.
Contin.	Continuously	Force measurement results are continuously transferred from the force gauge always. (no push key and no stability required)



- To enable the Wireless transmitter, select Bluetooth and press the Enter key. Select Status and use the navigation keys to select ON. (Available on FC models only)

**INTERFACE**

1. RS-232C
2. USB
3. Bluetooth
4. Exit

**BLUETOOTH**


1. Status: < On, Off >
2. Sending: < normal, No STB, Auto STB, Remove >
3. Exit

## 12.4 LCD Settings

- To adjust LCD contrast and configure backlight settings select LCD Settings from the Configuration menu and press the Enter key.

**CONFIGURATION**


1. Printout
2. Interface
3. LCD Settings
4. Time & Date
5. Keypad
6. Auto-Off
7. Battery



- Use the navigation keys to select and configure LCD settings.

**USB**

1. Contrast:
2. Backlight: < BAT, On, Off, ECO >
3. Direction: < Auto, Up, Down >
4. Time LCD: < On, Off >
5. Exit





### Backlight Settings

<b>BAT</b>	The backlight is turned off after 30 seconds of inactivity to preserve battery life.
<b>ON</b>	The backlight is always on.
<b>OFF</b>	The backlight is always off.
<b>ECO</b>	The backlight can be turned on by holding the backlight key on the main keyboard.

### LCD Direction Settings

<b>UP</b>	The screen is always upright
<b>DOWN</b>	The screen is always upside down.
<b>AUTO</b>	The screen automatically adjusts to the direction the force gauge is being held.


### Time LCD Settings

<b>ON</b>	Date and time is shown on the LCD
<b>DOWN</b>	Date and time in

## 12.5 Time & Date


- To adjust the force gauge Time and Date select Time & Date from the configuration menu and press the Enter key.

CONFIGURATION	
1. Printout	
2. Interface	
3. LCD Settings	
<b>4. Time &amp; Date</b>	
5. Keypad	
6. Auto-Off	
7. Battery	





- Use the navigation keys to select and change the time settings.

TIME & DATE	
1. Time:	11:45:30 AM
2. Date:	11 – 29 – 2016
3. 12 / 24:	< 12H, 24H >
4. Format:	< MM-DD-YYYY, DD-MM-YYYY >
5. Exit	





## 12.6 Keypad – Disabling and Enabling Buzzer Feedback

1. To enable or disable the keypad buzzer feedback select Keypad from the Configuration menu and press the Enter key.





2. Use the navigation keys to select Sound and select On to enable the keypad buzzer or Off to disable it.





## 12.7 Auto-Off – Power Save Settings

1. To configure battery power-save options, select Auto-Off from the Configuration menu and press the Enter key.




- Use the navigation keys to select Status and press the Enter key to change the setting.



### Auto-Off Power Save Settings

<b>BAT</b>	The force gauge will shut off automatically when the battery is low.
<b>ON</b>	The force gauge automatically shuts off after 5 minutes of inactivity.
<b>OFF</b>	The force gauge will only turn off when the user presses the ON/OFF key.



## 12.8 Battery – Disabling Charging





**Always disable charging before installing disposable batteries.**

**Charging non-rechargeable, alkaline batteries can be hazardous and cause damage to the force gauge.**

- To disable charging select Battery from the Configuration menu and press the Enter key





- Use the navigation keys to select Charging and press the Enter key to change the setting.





### 12.9 External Input – Remote Triger (FC Models Only)

- To Enable the Input port which allows sending external button or a pedal to be used as trigger for starting force measurements, select External Input from the Configuration menu and press the Enter key.



- Use the navigation keys to select Status and press the Enter key to change the setting.



<b>Off</b>	Externa input port is disabled
<b>Trigger</b>	Capturing measurements or starting measurement sequence is initiated single external signal.
<b>Gate</b>	Measurements are captured only when the input port is enabled
<b>Print</b>	Single external signal initiates the Print command.





## 12.10 Firmware Update



Before updating the force gauge firmware please contact technical support for assistance.

To update the firmware, the force gauge must be connected to a PC via the USB port. A firmware update must be enabled simultaneously through Torbal Utility software on the PC as well as the Firmware option on the force gauge.

1. To initiate the firmware update, select Firmware Update from the Configuration menu and press the Enter key.





2. Use the navigation keys to select Yes and press the Enter key.





## 12.11 Defaults

1. To reset all modes and applications as well as restore default factory settings, select Defaults from the Configuration menu and press the Enter key.



2. Use the navigation keys to select Yes and press the Enter key.



# Chapter 13: Calibration


To access the calibration menu, press the Menu key, select Calibration and press the Enter key.

**USER MENU**

1. Applications
2. Data Manager
3. Measur. Settings
4. Configuration
- 5. Calibration**
6. Info
7. Exit

## 13.1 Calibrating with Mass or Force


1. Position the device upside down with the hook tip attached. The gauge should be secured into a stand.



2. Select Mode and the unit of measure (LOAD or FORCE)


**CALIBRATION**

1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.00N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	




- Select the *Load or Force* equal exactly to the weight or force of the calibration standard that will be used to calibrate. To enter a custom load or force value, press the right arrow key and key in the calibration value.

CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.00N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	




- Select *Calibration – START* and press the Enter key to initiate calibration.

CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.00N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	





- Press the enter key to start the calibration process.



CALIBRATION	200N
Press ENTER	



- When prompted place the calibration load on the hook or hook-held platform and press Enter. Wait for the calibration process to complete.




- When prompted, key in your local Gravitational Acceleration Value and press the Enter key to complete the calibration process.



### 13.2 Setting Gravitational Acceleration Value

1. To calibrate the force gauge using the navigation keys to select g [ m/s<sup>2</sup> ] and press the Enter key.

CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.00N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	




2. Use the navigation keys to key in the gravitational acceleration for the location area the force gauge is used in. The g-value of a given location can be found on the web. (e.g. Wikipedia, local municipality site, etc.) If the g-value cannot be obtained, the geographical coordinates can be entered to calculate the g-value automatically.

### 13.3 Using Geographical Location Coordinates

1. To key in the Geographical Coordinates for the area the force gauge is used in, select Geogr. Location and press the Enter key.


CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.00N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	



2. Enter the *Latitude* of the current location and press Enter to continue.
3. Enter the *Elevation* of the current location and press Enter to save. The g-value will be automatically updated.


### 13.4 Setting a Correction Value

1. Position the device upside down with the hook tip attached. The gauge should be secured into a stand.
2. Place the calibration load on the hook or hook-held platform.



3. Note the difference between the known calibration load and the measured load.
4. Select *Correction* and key in the noted difference.


CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.90N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	



### 13.5 Setting Load Cell Sensitivity mV/V (Use when interchanging load-cells)

- To key in load-cell MAX and mV/V sensitivity values, use the navigation keys to select Load-cell and press the enter key

CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.90N >
<b>7. Load-Cell</b>	<b>&lt; MAX = 0 kg, SENS=0.00000 mV/V &gt;</b>
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	




- Use the navigation keys to key in the MAX value of the load-cell and press the Enter key to continue.
- Use the navigation keys to key in the mV/V SENS (sensitivity) value of the loadcell and press the Enter key.

**MAX and mV/V values are located on the load-cell nameplate or Calibration Certificate.**

### 13.6 Restoring Factory Calibration

- To restore factory calibration select Factory Calibr. and press the Enter key.


CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.90N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
<b>8. Factory Calibr.</b>	<b>&lt; Yes, No &gt;</b>
9. PIN	< ***** >
10. Exit	








- Use the navigation keys to select Yes and press the Enter key to proceed.




### 13.7 Calibration PIN Access

- To enable PIN access to the calibration menu select PIN and press the Enter key.




- Use the navigation to set a 6-digit calibration PIN. The PIN must be confirmed to become active. To disable PIN access change the PIN number to 000000




# Chapter 14: Force Gauge Info

1. To verify the force gauge firmware version and serial number, press the Menu key, select Info and press the Enter key.



**USER MENU**

1. Applications
2. Data Manager
3. Measur. Settings
4. Configuration
5. Calibration
- 6. Info**
7. Exit



2. Force gauge serial number, firmware and other important data will be displayed.

**INFO**

Model : FC200  
 MAX : 200 N  
 SOFT. : FCF008  
 DATE : 2015.11.24  
 S/N : F22002001031  
 CARD : SDHC 3.69GB  
 TORBAL

# Chapter 15: Interchanging Load-Cells (FC1k - FC50k Models Only)

## 15.1 Adding New Load-Cells

1. Enable the Gauge Type feature in the Configuration Menu. Use the navigation keys to select Gauge Change and press Enter. Change the status to Enable. The Gauge Type feature setup and list will be available in the Main Menu.

<p><b>CONFIGURATION</b></p> <ol style="list-style-type: none"> <li>1. Printout</li> <li><b>2. Gauge Change</b></li> <li>3. Interface</li> <li>4. LCD Settings</li> <li>5. Time &amp; Date</li> <li>6. Keypad</li> <li>7. Auto-Off</li> </ol>	<p><b>GAUGE CHANGE</b></p> <ol style="list-style-type: none"> <li>1. Status: &lt; Enable, Disable &gt;</li> <li>2. Exit</li> </ol>
--	--

1. Press the Menu key and select Gauge Type

**USER MENU**

- 1. Gauge Type**
2. Applications
3. Data Manager
4. Measur. Settings
5. Configuration
6. Calibration
7. Info

2. Use the navigation keys to select Setup


**GAUGE TYPE**

FC00-01: FC1K  
**Setup**




- To add a new load-cell to the Gauge Type list, select an empty slot marked NONE and press the Enter key. Use the navigation keys to key unique loadcell name if necessary. Select a load-cell model from the list.

GAUGE TYPE		
No.	NAME	TYPE
01.	FC00-01:	FC1K
02.	FC00-02:	NONE < FC1k, FC2k, FC5k, FC10k, FC20k >
03.	FC00-03:	NONE
04.	FC00-04:	NONE
05.	FC00-05:	NONE
06.	FC00-06:	NONE
07.	FC00-07:	NONE




## 15.2 Selecting and Enabling Load-Cells

- Press the Menu Key and select Gauge Type from the Main Menu.




USER MENU	
1.	Gauge Type
2.	Applications
3.	Data Manager
4.	Measur. Settings
5.	Configuration
6.	Calibration
7.	Info
	...




- Use the navigation keys to select a load-cell from the list and press the Enter key.

GAUGE TYPE	
<input checked="" type="checkbox"/>	FC00-01: FC1K
<input type="checkbox"/>	FC00-02: FC2K
<input type="checkbox"/>	FC00-03: FC5K
	Setup




- Press the Menu key and select Calibration from the Main Menu.



USER MENU	
1.	Applications
2.	Data Manager
3.	Measur. Settings
4.	Configuration
5.	Calibration
6.	Info
7.	Exit

4. Use the navigation keys to select Load-cell and press the Enter key

CALIBRATION	
1. Calibration	START
2. Mode:	< N/kN, kgf, lbf, ozf, kg, lb, oz >
3. Force:	< 200 N, ... >
4. g [ m/s <sup>2</sup> ]:	< 9.81416 >
5. Geogr. Location	< Latitude: 54°21', Elevation 114m >
6. Correction	< + 0.90N >
7. Load-Cell	< MAX = 0 kg, SENS=0.00000 mV/V >
8. Factory Calibr.	< Yes, No >
9. PIN	< ***** >
10. Exit	




5. Use the navigation keys to key in the MAX value of the load-cell and press the Enter key to continue.  
 6. Use the navigation keys to key in the mV/V SENS (sensitivity) value of the loadcell and press the Enter key.


**MAX and mV/V values are located on the load-cell nameplate or Calibration Certificate.**

## Chapter 16: Connecting to PC - Communication Protocol


1. Before connecting the force gauge to a computer, the USB Port must be configured with the appropriate baud rate and other necessary parameters.
2. Make sure you PC or Laptop is connected to the internet and allows drivers to be installed automatically.
3. Connect the force gauge to the PC with a Standard A/B USB cable.



4. Allow the USB drivers to install automatically. If the driver does not install automatically, visit [torbalscales.com](http://torbalscales.com) to download and install the driver manually.



- Verify the COM port number assigned the force gauge. Open the PC Device Manager, expand the Ports (COM & LPT) tab and locate the USB Serial Port (Note the COM port listed). The COM port is also listed in the FT232R USB UART device properties, which is visible in the Devices and Printers list, accessible from the computer's control panel.



- Once the COM port number assigned to the force gauge has been verified, open the software application and set the software connection to the COM port number listed in the PC device manager and the Baud Rate set in the force gauge.


## 16.1 Force Gauge Communication Protocol

Computer → Force Gauge: ENQ = (S I CR LF), (53 h 49 h 0Dh 0 Ah),

Force Gauge → Computer: 16 Bytes, 8 bits, 1stop, no parity, 4800bps

Transmission initiation command (Print key) ENQ= (S I CR LF)

Use Sx1"+CR+LF to request data from PC without stable result.



1	-	space or mark
2	-	Space
3÷4	-	digit or space
5÷9	-	digit, decimal point or space
10	-	Digit
11	-	Space
12	-	K,l,c,p or space
13	-	G,b,t,c or %
14	-	Space
15	-	CR
16	-	LF



# Chapter 17: Wireless PC Connection (FC Models Only)

1. To enable the Wireless transmitter, press the Menu key and select Configuration.

**USER MENU**

1. Applications
2. Data Manager
3. Measur. Settings
- 4. Configuration**
5. Calibration
6. Info
7. Exit

2. Use the navigation keys to select Interface and press the Enter key

**CONFIGURATION**

1. Printout
- 2. Interface**
3. LCD Settings
4. Time & Date
5. Keypad
6. Auto-Off
7. Battery

3. To enable the Wireless transmitter, select Bluetooth and press the Enter key. Select Status and use the navigation keys to select ON.


**INTERFACE**

1. RS-232C
2. USB
- 3. Bluetooth**
4. Exit


**BLUETOOTH**

1. Status: < On, Off >
2. Sending: < normal, No STB, Auto STB, Remove >
3. Exit


4. Make sure your PC is connected to the internet and allows drivers to be installed automatically. Plug in the dongle to an available USB slot in your PC. Windows will begin automatic installation of device driver software.




5. Once the driver is installed, a Bluetooth icon will be visible in the task bar. Right click on the Bluetooth icon. The icon may be hidden, in which case expand your task bar to show all inactive icons. From the icon function menu select "Add a Bluetooth Device" to start the pairing wizard.




6. Device window with available devices will appear on the PC screen. Locate device "FC..." force gauge device, click once to select it, and click on Pair to proceed.




7. Key in the pairing code: 867225. Click next to pair the force gauge with your computer.



8. Click on the Bluetooth icon located in your task bar and select “open settings”.



- For convenience check off option “show the Bluetooth icon in the notification area” in the Options tab. Click on the tab “COM ports”, the serial COM ports used by your computer for Bluetooth will be displayed. Note the outgoing COM port number for “FC... ‘SPP Dev’”. This is the COM port used the PC computer to transmit data between the force gauge and the PC.




- Once the COM port number assigned to the force gauge has been verified, open the software application and set the software connection to the COM port number listed in COM Ports Bluetooth settings. Use Baud Rate 115200.

# Chapter 18: Input / Output Port Configuration (FC Models Only)

The threshold output mode enables the Output port by sending voltage level signals which can be used for signaling or controlling external peripherals that can connect with the force gauge. The output mode can be used in combination with Programmable Thresholds Monitoring. Input mode allows external button or a pedal to be used as trigger for starting force measurements and taking samples.

OUTPUT Ampacity:  $I_{max}=25\text{mA}$  /  $U_{nom}=24\text{V}$  (open collector type, emitters connected– GND)


INPUT Voltage Range IN (+)/IN (-):  $U_{in}=12\text{-}18\text{V}$  /  $I_{in\ max}=50\text{mA}$



Outputs MAX and ZERO: Equivalent (common GND)


Recommended Power: 24V<sub>DC</sub>

MIN, MAX, ZERO Output Current:  $I_{out\ max} = 25\text{mA}$



Supply voltage:  $U_{in} = 3 \div 6\text{V}$

Input current:  $I_{in} = 10 \div 20\text{mA}$  ( $I_{in\ max} = 50\text{mA}$ )





## Chapter 19: Common Errors and Troubleshooting

<b>Error or Indicator</b>	<b>Cause</b>	<b>Explanation / Solution</b>
ZEROING is displayed for an extended period.	The initializing process was interrupted	Don't move the force gauge and press →0← ENTER key.
AD range exceeded (+/-)	The initializing process interrupted. Possible overload or load-cell damage	Put the gauge in horizontal position and turn it off and on using the <i>ON/OFF</i> key. Contact technical support.
The values indicated by the force gauge differs significantly from the reference.	Calibration may be required.	Contact a servicing facility to calibrate the gauge.

## Chapter 20: Maintenance


### **Cleaning and maintaining your force gauge:**

- Before cleaning the force gauge always unplug the A/C adapter from the electrical outlet and remove the batteries.
- Use a soft, slightly damp cloth to clean the exterior housing of the force gauge.
- Wipe the force gauge gently. Do not allow any liquid to enter into the force gauge.
- Do not apply extensive pressure to the LCD display.
- Do not use chemicals or benzene when cleaning the surface. Corrosive chemicals may damage the finish.

# Chapter 21: Accessories


### Hex key Clamp

This chrome-plated hex key vise clamp is ideal when performing peel testing, or gripping thin material such as film, paper, or foil. The vise is equipped with an adjustable hex key screw and interlocking claps which allow for secure sample gripping without damage.




### C-Clamp

This chrome-plated manual C-Clamp is designed to secure samples on the testing stand. The clamp also easily attaches to the force gauge and it is ideal for making measurement on wide range of sample shapes and sizes. This attachment should be used when testing samples that need to be gripped over a large surface area.



### Roller Grip

The roller grip attachment is used when measuring tape strength as well as tape adhesives. The grip is ideal for testing any sample that needs to be draped to obtain an accurate force measurement.



### Two-Grip Handle

The two-grip handle adapter is especially useful when performing force measurements between 200N and 500N. The handle securely mounts the force gauge meter allowing users a comfortable and firm grip when pulling or pushing objects that require extensive force.















### Hook Plate

The hook plate allows the TORBAL force gauges to be securely suspended in a hanging position. The hook can be used on all FA models with built-in load-cells. Hanging the force gauge is particularly useful when measuring articles which must be hung on the force meter to measure downward pull forces.






## Chapter 22: Replacement Parts


Part Name	Force Gauge Model	Image
Shaft Extension	FB/C50 – FB/C500	
Hook	FB/C50 – FB/C200	
Hook	FB/C500	
Chisel Point	FB/C50 – FB/C500	
V-Groove	FB/C50 – FB/C500	
Cone Point	FB/C50 – FB/C500	
Flathead	FB/C50 – FB/C500	
Swivel Bearing Joint	FB/C1k – FB/C10k	
Swivel Bearing Joint	FB/C20k	
Swivel Bearing Joint	FB/C50k	
Batter Pack Cover	all models	
Indicator Stand	FB/C..k	

# Chapter 23: Technical Information, Measurements and Dimensions


## FB/C5 to FB/C500




FB/C5 to FB/C500




FB1k...5k / FC1k...5k




FB10k / FC10k




FB100k...150k / FC100k...150k



FB20k / FC20k




FB50k / FC50k




(imperial)


FB1k...5k / FC1k...5k




FB10k / FC10k




FB100k...150k / FC100k...150k



FB20k / FC20k




FB50k / FC50k





(metric)

### FB200k & FC200k




(imperial)

### FB200k & FC200k




(metric)


Hook (FB/C5 to FB/C200)




Hook (FB/C500)




Shaft Extension




Flathead




Cone Point



V-Groove




Chisel Point




(imperial)




Hook (FB/C5 to FB/C200)




Hook (FB/C500)




Shaft Extension




Flathead




Cone Point



V-Groove




Chisel Point



(metric)


SJJ05




Operating range: 0 - 0.118





SJJ11



Operating range: 0 - 0.157




SJJ13



Operating range: 0 - 0.197



(imperial)

SJJ05





Operating range: 0 - 3 mm

SJJ11



Operating range: 0 - 4 mm

SJJ13



Operating range: 0 - 5 mm

(metric)



## Chapter 24: Limited Warranty

### PURCHASER'S WARRANTY

**Warranty is valid only if your product has been registered within 30 days of receipt**

This product is a precision device made to exacting standards of scientific accuracy. It is guaranteed to have been adjusted and inspected for proper workmanship and performance, and certified for its currently advertised specifications before shipment. Scientific Industries' Products are warranted against defects in material and workmanship under normal use and service. This warranty is extended only to the first purchaser. This limited warranty will not apply if, upon inspection, it is found that the product was tampered with, misused, overloaded, or abused, mishandled, placed in an improper environment, improperly installed or adjusted, used for a purpose other than that for which it was designed, or repaired by unauthorized personnel. Scientific Industries' liability under this warranty is limited to furnishing labor and parts necessary to remedy the defect covered by this warranty and restore the product to normal operating condition. Purchasers may be charged a minimum repair fee for in-warranty products returned for repair if those products are determined to be problem-free. To make a claim under this limited warranty, you must first obtain an RMA number from Scientific Industries and return the product carefully packed, in its original packaging, shipping prepaid, with the RMA number written on the return package.

EXCEPT FOR THE LIMITED WARRANTY PROVIDED HEREIN, ALL OTHER WARRANTIES, EXPRESS AND IMPLIED, INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE DISCLAIMED. In all events, consequential, incidental, special and other damages are excluded and Scientific Industries, Inc. shall have no liability beyond the repair or replace limited warranty provided above.



**SI** *Division of*  
**Scientific Industries, Inc.**

**Scientific Industries, Inc.**

80 Orville Dr.

Bohemia, NY 11716

Tel. (973)473-6900

Fax. (973)777-8302

[www.torbalscales.com](http://www.torbalscales.com)