INSTALLATION GUIDE

RephiDuo Clinical Pack

RephiLe Catalogue Number:
RR400Q401
Corresponding Millipore Part Number:
CP2ALLRES

Suitable Millipore Systems:
AFS 8 and 16

This product is comparable to the corresponding Millipore cartridge. Please refer to Millipore's User Manual for a detailed instruction on installation.

A Brief description of the installation process is described below:

1. Put the system into " STANDBY" mode by pressing "OPERATE/STANBY" button for two seconds. **Do not turn off the electrical power.**
2. Open the point-of-use valve for a few seconds to depressurize the system.
3. Lift up the pack adapter cap.
    - Remove the metal locking clip from the metal guide pin.
    - Remove the old pack from the system.
4. Remove the two blue protective caps on the new cartridge. Wet the two O-rings on the cartridge with a few drops of pure water.
5. Push the new cartridge so that the pack adapter metal rod goes through the hole at the top of the cartridge.
    - Lift the cartridge and push the bottom of it into the small opening on the system.
    - Push the top of the cartridge towards the system until it is secure.
6. Lock the cartridge in place with the metal locking clip on the end of the metal guide pin.
7. Bring the adapter cap down to its lowest position so that it covers the top of the cartridge.
8. Put the system into PRE-OPERATE mode by pressing the OPERATE/STANDBY button for two seconds.
9. Start the automatic AIR PURGE cycle by moving the point-of-use trigger down.
10. At the end of the 5-minute AIR PURGE cycle, the system goes automatically into STANDBY mode. Move the trigger back to close the point-of-use valve and put the system into PRE-OPERATE mode.
11. Install the final filter if needed.

RephiSolo, RephiDuo and RephiQuatro are trademarks of RephiLe Bioscience, Ltd.
© 2010. RephiLe Bioscience, Ltd. All rights reserved.
All other trademarks are trademarks of their respective manufacturers.