INSTALLATION GUIDE

RephiSolo P Pack 3

RephiLe Catalogue Number:
RR400CP03
Corresponding Millipore Part Number:
PR0G00003

Suitable Millipore Systems:
AFS 8 and 16

This product is comparable to the corresponding Millipore cartridge. Please refer to Millipore's User Manual for a detailed instruction on installation.

A Brief description of the installation process is described below:

1. Put the system into "STANDBY" mode by pressing "OPERATE/STANBY" button for two seconds. The "STANDBY" display flashes to indicate depressurization of the system.

2. Open the door on the front of the system by pressing the two latches on the right side of the door.

3. Pull out the old cartridge.

4. Remove the two blue protective caps on the new cartridge. Wet the two O-rings on the cartridge with a few drops of pure water.

5. Install the new cartridge and push it in as far as it will go. The message "Cartridge out" should disappear from the display.

 Attention!

The cartridge is directional. Please install in the direction as indicated by the "This Side Up" arrow.

6. Close the door firmly. **It is necessary for <u>both</u> latches to snap shut securely, to maintain the cartridge inside the system.**

7. Place the system back into "OPERATE" mode by pressing the "OPERATE/STANBY" button for two seconds. The system will automatically perform a flush and return to the normal production mode.

8. Proceed to the installation of a new Clinical Pack cartridge where required.

RephiSolo, RephiDuo and RephiQuatro are trademarks of RephiLe Bioscience, Ltd.
© 2010. RephiLe Bioscience, Ltd. All rights reserved.
All other trademarks are trademarks of their respective manufacturers.