

# USAGE/ASSEMBLY INSTRUCTIONS Fixed-Height Chairs

# MODELS:

# 12CPS, 12CPT, 12CUS, 12CUT 12CUSX, 12CUTX, 12CUSXX, 12CUTXX

# **Assembly Instructions**

#### **Attach Seat:**

- When chair is equipped with a molded plastic seat- place the seat on to chair frame. Tighten seat to frame with the supplied nuts using a 7/16" socket or wrench.
- When chair is equipped with upholstered seat and back- place chair face down
  and mount upholstered backrest to chair frame using the <u>supplied stainless steel</u>
  <u>bolts</u>. (Only use stainless steel bolts, regular steel bolts could stretch causing the
  chair back to loosen) Place the seat on the frame with rounded corners facing out.
  Bolt the seat down with the supplied bolts using a 7/16" socket or wrench.

### **Attach Arm Adjusters:**

• Attach one arm adjuster on each side of chair using a 7/16" socket or wrench.

#### **Install Arms:**

• Insert arm posts into arm adjuster. Place flip-up arm on right side of chair. Place straight arm on left side of chair.

# **Usage Instructions**

# **Arm Adjustment:**

- To adjust armrests loosen the black adjuster handle and move the arm up/down or left/right. Re-tighten handle to secure arm into position. The black adjuster handle position can be adjusted by pressing in gray handle button and rotating handle
- Adjust angle of the "flip-up" arm by rotating adjustment knob underneath armrest