

- "no L", the instrument can not adjust the light level. Please check that the sample does not contain any debris.

no L

- "L Lo", there is not enough light to perform a measurement. Please check the preparation of the zero cuvet.

L Lo

- "L Hi", there is too much light to perform a measurement. Please check the preparation of the zero cuvet.

L Hi

On sample reading

- "-SA-", there is too much light for the sample measurement. Please check if the right sample cuvet is inserted.

-SA-

- "Inv", the sample and the zero cuvet are inverted.

Inv

- "ZEr0", a zero reading was not taken. Follow the instruction in the measurement procedure for zeroing the meter.

ZEr0

- Under range. A blinking "0.00" indicates that the sample absorbs less light than the zero reference. Check the procedure and make sure you use the same cuvet for reference (zero) and measurement.

0.00

- A flashing value of the maximum concentration indicates an over range condition. The concentration of the sample is beyond the programmed range: dilute the sample and re-run the test.

5.00

BATTERY REPLACEMENT

Battery replacement must only take place in a non-hazardous environment.

Simply rotate the battery cover on the back of the meter.

Detach the battery from the terminals and attach a fresh 9V battery while paying attention to the correct polarity. Insert the battery and replace the cover.



ACCESSORIES

MI504-100	Free & Total Chlorine reagent set (100 tests)
MI509-100	pH reagent (100 tests)
MI511-100	Free & Total Chlorine and pH reagent set (100 tests)
MI0001	Glass cuvetts (2 pcs)
MI0002	Caps for cuvetts (2 pcs)
MI0003	Stoppers for cuvetts (2 pcs)
MI0004	Tissue for wiping cuvetts (4 pcs)
MI0005	9V battery (1 pc)

CERTIFICATION

Milwaukee Instruments conform to the CE European Directives.



Disposal of Electrical & Electronic Equipment.

Do not treat this product as household waste. Hand it over to the appropriate collection point for the recycling of electrical and electronic equipment.

RoHS
compliant

Disposal of waste batteries. This product contains batteries. Do not dispose of them with other household waste. Hand them over to the appropriate collection point for recycling.



Please note: proper product and battery disposal prevents potential negative consequences for human health and the environment. For detailed information, contact your local household waste disposal service or go to www.milwaukeeinstruments.com (USA & CAN) or www.milwaukeeinst.com.

RECOMMENDATION

Before using this product, make sure it is entirely suitable for your specific application and for the environment in which it is used. Any modification introduced by the user to the supplied equipment may compromise the meter's performance. For your and the meter's safety do not use or store the meter in hazardous environment. To avoid damage or burn, do not perform any measurement in microwave ovens.


WARRANTY

These instruments are warranted against defects in materials and manufacturing for a period of 2 years from the date of purchase. This warranty is limited to repair or free of charge replacement if the instrument cannot be repaired. Damage due to accidents, misuse, tampering or lack of prescribed maintenance is not covered by warranty. If service is required, contact your local Milwaukee Instruments Technical Service. If the repair is not covered by the warranty, you will be notified of the charges incurred. When shipping any meter, make sure it is properly packaged for complete protection.

USER MANUAL

MI411

PRO Free & Total Chlorine & pH Photometer



milwaukeeinstruments.com (USA & CAN)
milwaukeeinst.com




Dear Customer,
Thank you for choosing a Milwaukee Instruments product.
This manual will provide you with the necessary information
for the correct use of the instrument. Please read it carefully
before using the meter.

SPECIFICATIONS

Free & Total Chlorine	
Range	0.00 to 5.00 mg/L Cl ₂
Resolution	0.01 mg/L (0.00-3.50 mg/L); 0.10 mg/L (above 3.50 mg/L)
Precision	±0.06 mg/L @ 1.50 mg/L
Method	Adaptation of the USEPA method 330.5 and Standard Method 4500-Cl G.
pH	
Range	6.5 to 8.0 pH
Resolution	0.1 pH
Precision	±0.1 pH @ 7.2 pH
Method	Adaptation of the phenol red method.
Other	
Light Source	Tungsten lamp
Light Detector	Silicon Photocell and 525 nm narrow band interference filter
Environment	0 to 50 °C (32 to 122 °F) 100% RH max
Battery Type	9 volt (1 pc)
Auto-Shut off	After 10' of non-use
Dimensions	192 x 104 x 52 mm (7.5 x 4.1 x 2")
Weight	380 g

CHANGE PARAMETER

To change parameter between Free & Total Chlorine and pH, press and hold for 3 seconds, the ZERO key.
The selected parameter will be displayed as "Cl" (chlorine) or "PH" on the display.



MEASUREMENT PROCEDURE


1. Turn the meter on by pressing ON/OFF. The last selected parameter is displayed on the Liquid Crystal Display ("Cl" or "PH").

- 2. Choose the parameter that you want to measure.
- 3. Fill the cuvet with 10 mL of sample, up to the mark, and replace the cap.
- 4. Place the cuvet into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 5. Press ZERO and "SIP" will blink on the display.
- 6. After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for measurement.




For Free Chlorine measurement

- 7. Add 3 drops of DPD 1 reagent and 3 drops of DPD 2 reagent to an empty cuvet.
- 8. Immediately add 10 mL of unreacted sample. Replace the cap and shake gently.



- 9. Immediately reinsert the cuvet into the holder and ensure that the notch on the cap is positioned securely on the groove.
- 10. Press READ and "SIP" will blink during measurement.



- 11. The instrument directly displays concentration in mg/L of free chlorine.

For Total Chlorine measurement

- 12. Remove the the cuvet and add to the reacted sample 3 drops of DPD 3 reagent. Replace the cap and swirl gently.
- 13. Reinsert the cuvet into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 14. Wait for 2 minutes 30 seconds then press READ and "SIP" will blink during measurement.



- 15. The instrument directly displays concentration in mg/L of total chlorine.

For pH measurement

- 16. Fill a cuvet with 10 mL of unreacted sample up to the mark.
- 17. Add 5 drops of pH-0 reagent. Replace the cap and shake gently.
- 18. Insert the cuvet into the holder and ensure that the notch of the cap is positioned securely into the groove.
- 19. Press READ and "SIP" will blink during measurement.
- 20. The instrument directly display the pH value.



GUIDE TO DISPLAY CODES


This prompt appears for 1 second each time the instrument is turned on.




The dashes "- - -" indicates that the meter is in a ready state and zeroing can be performed.




Sampling In Progress. Flashing "SIP" prompt appears each time the meter is performing a measurement.




"-0.0-", the meter is in a zeroed state and measurement can be performed.



The blinking "BAT" indicates that the battery voltage is getting low and the battery needs to be replaced.



"-bA-", the battery is dead and must be replaced. Once this indication is displayed, the meter will lock up. Change the battery and restart the meter.



"Conf", the meter has lost its configuration. Contact your dealer or the nearest Milwaukee Customer Service Center.



ERROR MESSAGES

On zero reading

•Blinking "-0.0-" indicates that the zeroing procedure failed due to a low signal-to-noise ratio. In this case press ZERO again.

