

KEY FUNCTIONS

- ON/C** Turns the calculator on
Clears all calculator contents
(calculations, memory, etc.)
- M+** Adds the displayed value to
the memory
- M-** Subtracts the displayed value from
the memory
- MRC** First press recalls the memory total
Second press clears the memory total

AUTO POWER OFF

The calculator utilizes an auto power off feature which allows the elimination of the "power off" button. The calculator will automatically turn off after approximately six (6) minutes if no button has been pressed.

BATTERY REPLACEMENT

The primary power for the calculator comes from the solar cell; however, the backup battery will provide power for low light conditions. A faint display, no display in low light conditions, and missing segments are all indications that the backup battery must be replaced. Remove the battery cover, located on the back of the unit. Remove the exhausted battery and replace it with a new #389 silver oxide battery. Make certain to insert the new battery with the positive "+" size visible. Replace the battery cover.

Technical service

Web Resources

Visit the VWR's website at www.vwr.com for:

- Français, Español, Deutsch, Italiano, Português version
- Complete technical service contact information
- Access to VWR's Online Catalogue, and information about accessories and related products
- Additional product information and special offers

Contact us for information or technical assistance contact your local VWR representative or visit. www.vwr.com.

Warranty

VWR International warrants that this product will be free from defects in material and workmanship for a period of two (2) years from date of purchase. If a defect is present, VWR will, at its option, repair, replace, or refund the purchase price of this product at no charge to you, provided it is returned during the warranty period. This warranty does not apply if the product has been damaged by accident, abuse, misuse, or misapplication, or from ordinary wear and tear. For your protection, items being returned must be insured against possible damage or loss. This warranty shall be limited to the replacement of defective products. IT IS EXPRESSLY AGREED THAT THIS WARRANTY WILL BE IN LIEU OF ALL WARRANTIES OF FITNESS AND IN LIEU OF THE WARRANTY OF MERCHANTABILITY.

**GO TO VWR.COM FOR THE LATEST NEWS,
SPECIAL OFFERS AND DETAILS OF YOUR LOCAL
VWR DISTRIBUTOR**

Cat. No. 15551-118 / 818-0061

©2015 92-6023-70 Rev. 1 011115

