

Choice[®] MicroFiber Mop

White MicroFiber String Mop

Microfibers are tiny fibers that have been split to produce ultra-fine fibers estimated to be at least one-sixteenth the size of a human hair. When woven together these fibers create a surface area covered with millions of spaces between the

fibers to trap moisture, dirt and debris. This technology allows for the dirt and liquids to be “picked up” rather than being pushed around.



Composition and Attributes

- White 88% polyester/12% nylon microfiber string mop with blue headband and tailband
- Microfiber yarns attract and trap dirt and debris
- Terry knit structure enhances absorbency to increase efficiency
- Tubular knit construction with sewn head and tail bands provides added durability
- Lot number assures traceability
- Chemical resistant and non-abrasive
- Autoclavable
- Can be laundered and re-used

Applications

- Floor cleaning in critical environments
- Application of disinfectants
- Spill pick-up
- Works with most standard loop mop frames and bucket/wringer systems

Other Choice products:

- Choice[®] 700
- Choice[®] 800
- Choice[®] 900
- Choice[®] Edge
- Choice[®] SuperSorb
- Choice[®] Spiral Notebooks

Laundry Instructions

- Machine wash in warm soapy water. Do not exceed 150°F/65°C.
- Tumble dry low. Do not exceed 140°F/60°C.
- Do not use fabric softeners
- Up to 10% bleach solution can be used without harming the fabric. Bleach may cause color to fade.

Technical Data

Fiber Content	88% polyester / 12% nylon
Weight	310g/mop head
Sorbency Capacity (DI H ₂ O)	1500 mL/mop head

Notes:

- Technical data represented in this table are typical values at the time of publication. These should not be used as product specifications.
- Due to differences in test methods applied and equipment utilized by different wiper manufacturers, valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions
- Third party testing can be performed upon request

Order Information

Product	Number	Packaging	Mops/Case
Choice [®] MicroFiber Mop	CHMFM.24	Individually wrapped	24


Other Berkshire Products



Wipers




Mop Systems



Face Masks



Glove Liners



Documentation Systems



Swabs