

Durx® 670

55% Cellulose / 45% Polyester Nonwoven Cleanroom Wiper

Durx® 670 is a cellulose/polyester nonwoven wiper recommended for ISO Class 5 and above environments composed of a hydroentangled nonwoven blend of 55% cellulose and 45% polyester. This combination of properties provides Durx® 670 with the absorbency level, abrasion resistance, and chemical compatibility required for controlled environments and applications where both cleanliness and economy are of the most importance.



Key Attributes

- 55% cellulose / 45% polyester hydroentangled nonwoven blend
- No binders or other chemical additives

Benefits

- Excellent combination of the synthetic polyester strength and cleanliness with the absorbent characteristics of cellulose
- Smooth, highly absorbent and durable
- Low extractable levels and particle counts
- Chemically compatible with common cleaning and disinfecting solutions
- Autoclavable
- Economical

Applications

- Designed for use in ISO Class 5 and higher cleanroom environments
- General equipment wrap and wipe downs
- General purpose wiping applications
- Cleaning of lab equipment
- General wiping in component prep, compounding and wash areas
- Applying and removing cleaning and disinfecting solutions
- EC Regulation 1935 (2004) - Food contact compliant
- FDA 21 CFR - Food contact compliant
- Meets AMS 3819D requirements, Class 2, Grade A, Form 1
- Meets BMS 15-5 requirements

Environmental

- Complies with RoHS

Other ISO Class 5 and above nonwoven wipers

- BlueSorb® 750
- Durx® 770
- MicroFirst®
- MicroFirst LP®
- ProjX® 700
- Pro-Wipe® 750
- Pro-Wipe® 880
- ValuClean® Plus

Pre-Wetted Option

The same wiper material can be provided in pre-wetted formats for reduced VOC emissions, increased convenience, increased productivity, improved solvent control and cleaning protocol repeatability and reduced costs.

Sterile Validated Option

For aseptic processing areas, the same wiper material can be provided in a gamma irradiated validated sterile to a 10⁻⁶ sterility assurance level. Dry and pre-wetted versions available.

www.berkshire.uk.com

Contact: Tel + 44 1953 562800
enquiries@berkshire.uk.com

America	Tel 1 413 528 2602	info@berkshire.com
Europe	Tel + 44 1953 562800	enquiries@berkshire.uk.com
SE Asia	Tel 65 6252 4313	enquiries@berkshire.com.sg
Japan	Tel 81 3 4530 9883	master@berkshire.co.jp

Technical Data:

Attribute		Units	Value	Test Method
Basis Weight		g/m ²	68.0	TAPPI T-410
Caliper		µm	264	TAPPI T-411
Fibres	≥100µm	fibres/cm ²	160	IEST-RP-CC004.4 Sec 7.1.3/Sec 7.2.2 modified
Particles	≥0.5µm	x10 ³ /cm ²	10	IEST-RP-CC004.4 Sec 7.1.3/Sec 7.2.1 modified
Sorbency	Capacity	mL/m ²	320	IEST-RP-CC004.4 Sec 9.1 / Sec 9.2 modified
	Efficiency	mL/g	4.7	
	Rate	seconds	2	
Non-Volatile Residue	DI Water	g/m ²	0.028	IEST-RP-CC004.4 Sec 8.1.2
	IPA	g/m ²	0.0038	
Ions	Na ⁺	ppm	62	IEST-RP-CC004.4 Sec 8.2.2
	K ⁺	ppm	5.9	
	Ca ⁺⁺	ppm	22	
	Mg ⁺⁺	ppm	5.0	
	Cl ⁻	ppm	31	

Notes:

- Technical data represented in this table are typical values at the time of publication. These should not be used as product specifications.
- Due to differences in test methods applied and equipment utilised by different wiper manufacturers, valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions
- Third party testing can be performed upon request

Order Information:

Product	Number	Size	Shts/pk	Pks/cs	Style
Durx [®] 670	DR670040410	4x4" (10x10cm)	1200	10	Stacked
Durx [®] 670	DR670040440	4x4" (10x10cm)	300	40	Stacked
Durx [®] 670	DR670070712	7x7" (18x18cm)	300	12	Stacked
Durx [®] 670	DR670090910	9x9" (23x23cm)	300	10	Stacked
Durx [®] 670	DR670090920	9x9" (23x23cm)	300	20	Stacked
Durx [®] 670	DR670121220	12x12" (30x30cm)	150	20	Stacked
Durx [®] 670	DR670181810	18x18" (45x45cm)	150	10	Stacked

Other Berkshire Products



Wipers



Mop Systems



Face Masks



Glove Liners



Documentation Systems



Swabs