

Contec® Isopropanol

Available in three blends: 65%, 70% and 100%

Contec Isopropanol contains USP Grade Isopropanol (IPA) and USP Grade Purified Water. Filtered to 0.2μ, bottles are double-bagged to assure product quality. Each bottle has a lot code and expiration date for easy record keeping.

A convenient trigger sprayer with settings for stream or mist spraying is included with the 16 and 32 oz bottles. The stream setting is ideal for targeting specific hard to reach areas, while the mist setting is used to cover larger surfaces. Each leak-proof bottle is induction sealed, capped and shipped with an uninstalled trigger sprayer to eliminate the occurrence of leakage.

Applications:

- Surface cleaning
- Wipe down of products and equipment for pass through to controlled environments
- Use on gloved hands during gowning

Product Characteristics for 70% IPA

Appearance	Clear, colorless liquid
Odor	Characteristic alcohol
Water Quality	Meets the requirements of USP Grade Deionized Water
% IPA Contents (+/-3%)	67.9% - 72.1%
Specific Gravity (20°C)	0.872 - 0.883

FEATURE	BENEFIT
Contains USP Grade Isopropanol	• Evaporates and leaves extremely low residues • Eliminates mixing, filtration, processing and QC expense of in-house production of sterile Isopropanol water blends
Filtered through 0.2 micron in-line filter	• Eliminates the need for in-house filtration • Meets USP Grade Purified Water
Induction sealed bottles	• Reduces opportunity for leakage during shipment
Adjustable trigger spray	• Select spray or jet option
Plastic bottle	• Recyclable, no costly disposal
Double bagged	• To preserve product integrity
Lot numbered bottles	• Assures complete product traceability

NOT FOR RETAIL SALE. MATERIAL DATA SHEET AVAILABLE FOR PROFESSIONAL USER ON WWW.CONTECINC.COM.

Part No.	Description	Quantity
SB167030	70% Isopropanol, 16 oz (0.47L)	12 bottles/case
SB327030	70% Isopropanol, 32 oz (0.95L)	12 bottles/case
SB1287030	70% Isopropanol, 128 oz (3.8L)	4 bottles/case
SB1286535	65% Isopropanol, 128 oz (3.8L)	4 bottles/case
SB128100	100% Isopropanol, 128 oz (3.8L)	4 bottles/case

* Also available sterile. See website for product offering.



P.O. Box 530 • Spartanburg, SC 29304 USA
Tel: +1-864-503-8333
Toll Free (US, Canada, PR): 1-800-289-5762
Europe: +33 297437690
www.contecinc.com • disinfect@contecinc.com