

CHAIR LAB ERGO, STOP&GO CASTORS, 620-890

ECN.	132-1394	
Dimensions in mm	Backrest:	H 530 mm
	Seat:	H 620 - 890 mm W 460 mm D 470 mm
Packing data	Weight:	16,0 kg
	Volume:	0,17 m³



Basic equipment

Benefit

Seat and backrest	Extra large ergonomically shaped backrest with horizontal stitching, tapers upwards.	Relieves the strain on the spine and muscles. Healthy sitting posture due to the wide support for the back around the lumbar vertebrae. Pleasant microclimate on the back and optimum freedom of movement for the arms.
	Ergonomically shaped seating surface with chamfer integrated into the edge of the seat.	Automatically requires the sitting posture to be correct. The chamfers prevent blood congestion in the thighs.
	Synthetic leather upholstery: High-level synthetic leather. Resistant to disinfectants, washable and easy-care. Colour black	The soft and comfortable upholstery provides a comfortable feel. However, damages caused by sharp parts can not be excluded. Ideal for the use in production and laboratory.
Seat height	Stepless seat height setting from 620-890 mm supported by safety gas spring with protective cover.	Seat height can be adapted to nearly 95 % of all body sizes, the cover protects the gas spring from dust and dirt.
Technology	Permanent contact-backrest	This mechanism ensures that the backrest responds immediately to any movements of the upper body by following them. Thus, the back remains supported all the time. The backrest can also be locked into any tilt position if required.
	Seat inclination	Avoids a tilt-back of the hips in a bending forward position. The bigger seat angle between the thighs and the upper body additionally relieves the organism.
	Backrest height adjustment	The support area can be adapted in accordance to the user's body size.
	Quick adjustment	Every function can be operated comfortable and easy in sitting position.
Functional handles	Stable and robust functional handles on the maximum mobility and simple handling of the chair. backrest. Colour blue	Maximum mobility and simple handling of the chair.
Base	Black 5 star base made from plastic. Flat design.	Very high stability, longevity and safety Flat design prevents stumbling hazard.
Castors	Soft Stop & Go-castors for hard floors	Offer a superb level of stability. Blocks the chair when seated. Easily movable when there is no pressure on the chair.
Foot ring	Height adjustable, chrome-plated foot ring.	Wide foot plate provides good support. Height can be quickly and easily adjusted.
Standards	DIN 68 877 GS certificate for "tested safety" DIN EN ISO 9001 quality management DIN EN ISO 14001 environmental management	Verified by certificates from independent testing institutes, quality, environmental friendliness and procurement security.

EMAS tested environmental management
OHSAS 18001 occupational health and
safety management
EcoVadis CSR rating 2015 Gold.

Guarantee	10-year long-term-guarantee	Free shipping for spare parts during the whole period of validity
-----------	-----------------------------	--

Fahrbarer Hochstuhl