

close-it control seal | essential for sampling

Taking samples from sacks, boxes, bags, etc. with sampling lances is a common and time-proven practice. This produces holes through which easily flowing bulk goods could escape from the container. With the close-it seal, this can be prevented in an uncomplicated manner.

close-it has been especially developed for this purpose. The label has a sandwich-type structure (aluminium/ paper) and seals the container hermetically (vapour barrier). This virtually prevents hygroscopic powders from clumping together. The label is not just used to provide a hermetic seal. It is also used for providing quality control information (sampling date, release yes/no, name of tester, etc.).

The labels are available in different colours. With printing in red, blue, green, yellow, black, neutral, without printing in white.

close-it can be written on with ball-point pen, pencil or felt-tip marker.

The rear of the label is coated with a powerful adhesive. This means that close-it sticks firmly to most commercial containers, even to surfaces coated with fine powder, slightly moist or even frozen surfaces where conventional labels or adhesive tape will not stick.



Control seal close-it 95x95

Colour	Model	W x H mm	Pieces per roll	Price €	Quantity scale from	Scale price €	Item no.
red	printed	95 x 95	500		10		5303-0012 N4
yellow	printed	95 x 95	500		10		5303-0014 N4
blue	printed	95 x 95	500		10		5303-0015 N4
green	printed	95 x 95	500		10		5303-0016 N4
black	printed	95 x 95	500		10		5303-0011 N4
white	unprinted	95 x 95	500		10		5303-0002 N4

Accessories

Description	Price €	Item no.
close-it dispenser for labels with 95 x 95 mm		5303-9000 N4

Control seal close-it maxi 150x150

Colour	Model	W x H mm	Pieces per roll	Price €	Quantity scale from	Scale price €	Item no.
red	printed	150 x 150	250		10		5303-1012 N4
yellow	printed	150 x 150	250		10		5303-1014 N4
blue	printed	150 x 150	250		10		5303-1015 N4
green	printed	150 x 150	250		10		5303-1016 N4
black	printed	150 x 150	250		10		5303-1011 N4
white	unprinted	150 x 150	250		10		5303-1002 N4

Accessories

Description	Price €	Item no.
close-it dispenser for labels with 150 x 150 mm		5303-9100 N4