

General purpose trolley

P/N: 0111932 | SW 8x5/2

HUPFER
we make work flow



Technical data

Modular dimension:	591 mm lichtetes Maß von Bord zu Bord
Payload:	80 kg
Weight:	16.091 kg
Width:	895 mm
Depth:	595 mm
Height:	950 mm

Similar to illustration, technical modifications reserved. Without decoration.

Serving trolley in standard version with deep-drawn shelves.

Trolley in robust, self-supporting and hygienic design, made of high-quality stainless steel 1.4301. $\varnothing$ 1.0" (25 mm) round tube frame with 2 welded, 31.5 x 19.7" (800 x 500 mm) deep-drawn shelves with 0.4" (10 mm) high profile edge, lined with sound insulation on the underside, hygienically folded by 1.4" (35 mm) and rebated inwards, designed for easy cleaning. Push bars integrated on both sides into tube frame ensure good manoeuvrability. 4 polyethylene disc bumpers serve as bumpers and protect trolley on all sides as well as building-side walls from being damaged. Trolley runs on 4 swivel casters of which 2 with total locks, $\varnothing$ 4.9" (125 mm), with pin fastening.

The Hupfer serving trolley SW 8 x 5 / 2 is a welded model delivered ready for use, and has the greatest usable height between the shelves in comparison to other products, while at the same time providing an extensive range of additional options to choose from. The smooth and cavity-free raised edges makes this model easy to clean, and prevents dirt from accumulating in the corners.

Time and date of the request:
24.01.2024, 14:36:16

All information / dimensions are approximate, technical changes reserved. © Hupfer