



The folding backrest trolley is designed to meet the demands of the industrial sector by facilitating the movement of medium loads.

Thanks to its design, lightweight construction, and compact size, this trolley is easy to maneuver. Additionally, it perfectly fits trays and boxes that conform to the 600x400 standard, making it an essential tool for logistics.

The 35 mm thick platform is made of reinforced polypropylene, and its surface is non-slip. Two metal bars reinforce the platform, allowing the trolley to support loads of up to 300 kilograms.

## PRODUCT ADVANTAGES

- **Mobile** : High-quality wheels offering very low frictions.
- **Euro-standard** : Suitable for transporting all 600x400 Euro-standard trays.
- **Lightweight** : Its lightweight and compact design make it an ideal choice for industrial use.
- **Robust** : Its reinforced polypropylene platform and two metal bars ensure enhanced durability.
- **Secure** : The backrest features an anti-pinch mechanism at the joint, ensuring user safety.

## SPECIFICATIONS

|                     |                              |
|---------------------|------------------------------|
| SKU                 | 65021                        |
| External dimensions | 610 x 415 x 900 mm           |
| Load capacity       | 300 kg                       |
| Material            | Polypropylene                |
| Color               | Black                        |
| Platform type       | Non-slip                     |
| Wheel diameter      | Ø100 mm                      |
| Wheel model         | 2 fixed, 2 swivel with brake |
| Assembly            | Self-assembly                |
| Number of handles   | 1                            |
| Shipping time       | 5 working days               |