



PRODUCT DATA SHEET

Item Number	: MPBH100
Item Name	: PIG® Essentials Plus Universal Mat Pads
Liquids Absorbed	: Oil, Coolants, Solvents & Water
Contents/Package	: 100 pads/package
Number Per Pallet	: 30
Colour	: Grey
Dimensions	: 48 cm x 38 cm
Composition	: 100% Polypropylene
Absorbency	: 110 L/Package
Weight	: 6.5 Kg

Description

- Random assembly of large-diameter MeltBlown poly fibres creates a lofty layer
- Mat absorbs high volumes of liquid fast; great for catching overspray or soaking up spills
- Ultrasonic bond points fuse layers of fibres together — Mat keeps its shape even when completely saturated
- Top layer of lint-free SpunBond fabric provides extra strength; "dimples" add fast-wicking power
- Grey colour signifies Universal sorbency for easy visual identification
- Perforated every 19 cm lengthwise