



Item # _____

Job _____

PRINTED CIRCUIT BOARD CARRIERS

- **Safe and Practical:** Printed circuit board carriers provide a safe and efficient handling system for delicate circuit boards. $\frac{5}{8}$ " (13mm) slide spacing on center permits flexibility in separating boards for proper protection. Slides accommodate boards up to $\frac{1}{8}$ " (9mm) thick.
- **Adjustable:** Slide panels are adjustable to exact width of boards to be handled. Moveable retaining bars enable boards to be put in or taken out from either side.
- **Stackable:** Two or three carriers of the same size can be stacked vertically to save floor space.
- **Large Capacity:** Up to 20 full-size boards can be accommodated in each of the different carriers. With the addition of double-sided center panels, two or more boards can be carried on each level, so carriers can hold from 40 to 60 12"x6" (305x152mm) boards.
- **Easily Transported and Stored:** PCB carriers can be transported and stored in a variety of modified and standard products made by InterMetro:
 - In PT Series tote box carriers;
 - In enclosed mobile cabinets;
 - In adjustable undershelf slides made to fit standard Super Erecta Shelf® shelf carts and trucks.
- **Conductive:** Made of chrome-plated carbon steel.



CBC11C



CBC11C with Center Panel



InterMetro Industries Corporation
North Washington Street
Wilkes-Barre, PA 18705
www.metro.com



PRINTED CIRCUIT BOARD CARRIERS



Two CBC11C's Stacked



*Three CBC11C's in PT1C-5M Tote Box Carrier
(Capacity six CBC11C's. Two- and three-bay Tote Box Carriers also available).*

Dimensions

Model No.	Length/Width/Height (in.)	Length/Width/Height (mm)	Approx. Pkd. Wt. Per Unit (lbs.) (kg)	Maximum Board Size (in.)	Maximum Board Size (mm)	Capacity with Full-Size Boards	Capacity with 12"x6" (305x150mm) Boards
CBC11C	17 ¹ / ₂ x12 ¹ / ₂ x18 ³ / ₁₆	445x315x460	10 4.53	13x12	330x305	20	40 (1 Center Panel)
CBC13C	24 ¹ / ₄ x12 ¹ / ₂ x18 ³ / ₁₆	615x315x460	10 ³ / ₄ 4.87	19 ¹ / ₄ x12	489x305	20	60 (2 Center Panels)

Center Panel with Double Slide

Model No.	Length/Width/Height (in.)	Length/Width/Height (mm)	Approx. Pkd. Wt. Per Unit (lbs.) (kg)
CBCP2C	7 ⁷ / ₈ x12 ¹ / ₂ x15 ¹ / ₈	22x317x384	6 2.7

Load Rating: 5 lbs. (2kg) per slide, not to exceed 75 lbs. (34kg) per carrier.

All Metro Catalog Sheets are available on our website: www.metro.com



InterMetro Industries Corporation

North Washington Street • Wilkes-Barre, PA 18705 • 570.825.2741
 Fax: 800.638.9263 (East Coast/Canada) • Fax: 800.638.3292 (West Coast)

FOR PRODUCT INFORMATION/CUSTOMER SERVICE:
 U.S./Canada/Latin America: 1.800.992.1776 • Europe: +31.76.587.7550
 Asia/Pacific: +65.6567.8003 • Middle East/Africa: +971.4.811.8286

Information and specifications are subject to change without notice. Please confirm at time of order

L02-133e
 Rev. 02/12
 Printed in U.S.A.

Copyright © 2012 InterMetro Industries Corp.