



Item # \_\_\_\_\_

Job \_\_\_\_\_

## SPACE SAVER 24" (610mm) DEEP WORKTABLES

- **Built to Last:** The Space Saver 24" (610mm) Deep Stationary Worktables' sturdy construction provides a robust 800 lb. (363kg) load rating. Mobile tables are rated to 600 lbs. (272kg). Available preconfigured units consist of T-304 stainless steel components that stand up to the harshest applications and environments.
- **Proven Stability:** Space Saver worktables feature 1" (25mm) diameter posts and the tapered sleeves and corners of patented Super Erecta Shelf® construction. These features assure a rigid, sway-free table. The work surface is made of seamless, heavy-duty 14-gauge stainless steel that virtually eliminates any "drumming."
- **Easy to Assemble:** Units are shipped knocked down to save on freight, and can be put together in minutes without the use of special tools. Bottom shelf or frame is adjustable in 1" (25mm) increments. Table top fits over split sleeves at the top of the posts.
- **Stationary or Mobile:** Preconfigured units are offered both in stationary with a leveling foot and mobile utilizing a 5" (127mm) polymer caster. These innovative stem casters offer corrosion resistance and enhanced durability.
- **Popular Sizes:** Space Saver Worktables are offered in 24" (610mm) depth and 36" (914mm), 48" (1219mm) and 60" (1524mm) lengths. All models are 34" (860mm) high.
- **Customizable:** Preconfigured units are available in our T-304 stainless steel finish. Worktables can be ordered by component using Super Erecta® posts, frames and shelves in any finish for a solution that fits any price point or application.



*Stationary Worktable  
with 3-sided  
Double Snake Frame*



*Mobile Worktable with  
Stainless Steel  
Solid Undershelf*



**InterMetro Industries Corporation**  
North Washington Street  
Wilkes-Barre, PA 18705  
[www.metro.com](http://www.metro.com)



**Space Saver 24" (610mm) Deep Worktables**

**17.40**



## SPACE SAVER 24" (610mm) DEEP WORKTABLES

### Specifications:

- **Top:** Seamless 14 gauge T-304 stainless steel with 14 gauge T-304 stainless steel channel support.
- **Bottom Shelf:** 18 gauge T-304 stainless steel with black, epoxy-coated corners. 36" length worktables utilize 21x30" (533x762mm) undershelves, 48" length worktables utilize 21x42" (533x1067mm) undershelves, and 60" length worktables utilize 21x48" (533x1219mm) undershelves. Can be used with any Super Erecta® or Super Adjustable Super Erecta® wire or solid shelving.
- **Bottom Frame:** 3-sided double snake frame offered in 304 stainless steel. 36" length worktables utilize 21x30" (533x762mm) frames, 48" length worktables utilize 21x42" (533x1067mm) frames, and 60" length worktables utilize 21x48" (533x1219mm) frames.
- **Posts:** Stainless Steel posts have an outside diameter of 1" (25mm), with rolled grooves in 1" (25mm) increments along entire height.
- **Casters:** Mobile units feature 2 swivel/2 brake 5" (127mm) polymer caster with polyurethane tread. Can also be used with any standard Metro Stem Caster. (Note: changing casters may affect load rating. See Specification Sheet 11.20 for more details)

### Dimensions

#### Space Saver Worktables

24" (610mm) Wide

Stationary

Model No.	Length		Bottom Type	Approx. Pkd. Wt.	
	(in.)	(mm)		(lbs.)	(kg)
WTS2436FS	36	914	Solid Stainless Steel	64	29.0
WTS2448FS	48	1219	Solid Stainless Steel	81	36.8
WTS2460FS	60	1524	Solid Stainless Steel	93	42.3
WTS2436US	36	914	3-Sided Frame	53	24.1
WTS2448US	48	1219	3-Sided Frame	65	29.5
WTS2460US	60	1524	3-Sided Frame	75	34.1

**Load Rating:** Stationary Units are rated to 800 lbs. (363kg).

Mobile

Model No.	Length		Bottom Type	Approx. Pkd. Wt.	
	(in.)	(mm)		(lbs.)	(kg)
MWTS2436FS	36	914	Solid Stainless Steel	76	34.5
MWTS2448FS	48	1219	Solid Stainless Steel	93	42.2
MWTS2460FS	60	1524	Solid Stainless Steel	105	47.6
MWTS2436US	36	914	3-Sided Frame	65	29.5
MWTS2448US	48	1219	3-Sided Frame	77	34.9
MWTS2460US	60	1524	3-Sided Frame	99	44.9

**Load Rating:** Mobile Units are rated to 600 lbs. (272kg), evenly distributed. Mobile tables are intended for move-to-clean applications only and not as a transport device.

All Metro Catalog Sheets are available on our website: [www.metro.com](http://www.metro.com)



#### InterMetro Industries Corporation

North Washington Street, Wilkes-Barre, PA 18705

Phone: 570-825-2741

Product Information. U.S. and Canada: 1.800.992.1776

Outside U.S. and Canada: [www.metro.com/contactus](http://www.metro.com/contactus)

L03-201  
Printed in U.S.A. 2/17

Information and specifications are subject to change without notice. Please confirm at time of order.

Copyright © 2017 InterMetro Industries Corp.