

Model CB 56 \mid CO $_{2}$ incubators with hot air sterilization and heat sterilizable CO $_{3}$ sensor

The BINDER CB series CO_2 incubator is the premium class among the CO_2 incubators. It is suitable for all sensitive incubation applications and ensures optimal cell growth. A BINDER CB series CO_2 incubator can perform complex cultivation experiments as well as specific environmental conditions.

BENEFITS

- Safe cell cultures receive maximum protection against contamination
- Reliable constant well-being conditions for the cells
- Smart simple routine cleaning and convenient operation
- Economical efficient operation without consumables



Model 56

MAIN FEATURES

- Optimized humidification system with condensation protection
- Tried-and-tested anti-contamination concept with 180 °C hot air sterilization
- Hot-air sterilizable CO₂ sensor with single-beam infrared technology
- Seamless inner chamber made of stainless steel with flanges as shelf support system
- $\bullet~$ Fanless interior with Venturi $\text{CO}_{\tiny 2}$ gas mixing nozzle
- Intuitive touchscreen controller
- Internal data recording, can be read out in open format via USB interface
- Fault diagnosis system with visual and acoustic alarm
- Interfaces: Ethernet, USB, zero-voltage alarm contact
- $\bullet~$ Fail-safe $\text{CO}_{\tiny{2}}$ system for protecting the pH of cell cultures



Model 56

OPTIONAL EQUIPMENT

- O_2 control with O_2 control ranges: 0.2 to 20 vol.% O_2 or 10 to 95 vol.% O_2
- Multi-sectional glass doors with special shelves for dividing up the space to accommodate different experiments
- Stacking adapter for secure, space-saving installation
- Gas tank changer for connecting two gas tanks to one or two incubators

ORDERING INFORMATION

Interior volume [cu.ft.]	Voltage	Option model	Version	ArtNo.
1.9	200230 V 1~ 50/60 Hz	Standard	CB056-230V	9640-0005
		with O ₂ control 0.2–20%	CB056-230V-0	9640-0006
		Standard	CBo56UL-120V	9640-0007
	1	100120 V 1~ 50/60 Hz	with O ₂ control 0.2–20%	CB056UL-120V-0



TECHNICAL DATA

Description	CB056-230V1	CB056-230V-01	CB056UL-120V1	CB056UL-120V-01
Article Number	9640-0005	9640-0006	9640-0007	9640-0008
Performance Data Temperature				
Temperature range +4 °C above ambient temperature to [°C]	60		60	
Temperature range +6 °C above ambient temperature to [°C]		60		60
Temperature variation at 37 °C [± K]	0.3	0.3	0.3	0.3
Temperature fluctuation at 37 °C [± K]	0.1	0.1	0.1	0.1
Recovery time after 30 seconds door open at 37 °C [min]	5	5	5	5
Tabellen				
Humidity range	9095	9095	9095	9095
CO ₂ Recovery time after 30 seconds door open at 5 Vol% CO ₂ [min]	5	5	5	5
O_2 Recovery time after 30 seconds door open at 5 Vol% O_2 [min]		5		5
O ₂ Recovery time after 30 seconds door open at 10 Vol% O ₂ [min]		5		5
Energy consumption at 37 °C [Wh/h]	45	45	45	45
CO ₂ -Data				
CO ₂ range [Vol% CO ₂]	020	020	020	020
CO₂ measurement	IR	IR	IR	IR
O₂-Data				
Standard O_2 control ranges: O_2 range [Vol% O_2]		0.220		0.220
O_2 control ranges with option: O_2 range [Vol% O_2]		1095		1095
Electrical data				
Rated Voltage [V]	200230	200230	100120	100120
Power frequency [Hz]	50/60	50/60	50/60	50/60
Nominal power [kW]	0.8	0.8	0.8	0.8
Unit fuse [A]	10	10	16	16
Phase (Nominal voltage)	1~	1~	1~	1~
Measures				
Interior volume [cu.ft.]	1.9	1.9	1.9	1.9
Net weight of the unit (empty) [lbs]	117	117	117	117
Permitted load [lbs]	66	66	66	66
Load per rack [lbs]	22	22	22	22
Wall clearance back [in]	3.94	3.94	3.94	3.94
Wall clearance sidewise [in]	1.97	1.97	1.97	1.97
Internal Dimensions				
Width [in]	15.76	15.76	15.76	15.76
Height [in]	15.76	15.76	15.76	15.76
Depth [in]	13	13	13	13
Doors				
Inner doors	1	1	1	1
Unit doors	1	1	1	


¹ All technical data is specified for unloaded units with standard equipment at an ambient temperature of +22 °C ±3 °C and a power supply voltage fluctuation of ±10%. The temperature data is determined to BINDER factory standard following DIN 12880, observing the recommended wall clearances of 10 % of the height, width, and depth of the inner chamber. All indications are average values, typical for units produced in series. We reserve the right to change technical specifications at any time.



Description	CB056-230V1	CB056-230V-01	CB056UL-120V1	CB056UL-120V-01	
Article Number	9640-0005	9640-0006	9640-0007	9640-0008	
Housing dimensions not incl. fitting	s and connections				
Width net [in]	20.8	20.8	20.8	20.8	
Height net [in]	26.56	26.56	26.56	26.56	
Depth net [in]	21.47	21.47	21.47	21.47	
Environment-specific data					
Sound-pressure level [dB(A)]	41	41	41	41	
Fixtures					
Number of shelves (std./max.)	2/3	2/3	2/3	2/3	

¹ All technical data is specified for unloaded units with standard equipment at an ambient temperature of +22 °C ±3 °C and a power supply voltage fluctuation of ±10%. The temperature data is determined to BINDER factory standard following DIN 12880, observing the recommended wall clearances of 10 % of the height, width, and depth of the inner chamber. All indications are average values, typical for units produced in series. We reserve the right to change technical specifications at any time.

DIMENSIONS INCL. FITTINGS AND CONNECTIONS [MM]



OPTIONS

Designation	Description	*	ArtNo.
	back		
Access port with silicone plug	30 mm	01	8612-0025
	left		
	30 mm	01	8612-0026
	right		
	30 mm	01	8612-0027
Analog output 4-20 mA	for temperature and CO ₂ values (outputs not adjustable)	02	8612-0022
Calibration certificate, temperature	for temperature, measurement in center of chamber at specified temperature	-	8012-1132
	temperature measurement incl. certificate and 27 measuring points at specified temperature	-	8012-1592
	temperature measurement incl. certificate, 15-18 measuring points at specified temperature	-	8012-1571
	temperature measurement incl. certificate, 9 measuring points at specified temperature	-	8012-1550
Calibration certificate, temperature and CO ₂	for temperature and CO_2 , temperature measurement in center of chamber, CO_2 measurement performed using test gas at 37 °C and 5 % CO_2	-	8012-1235
Door hinged on the left	Unit door and standard glass inner door with door hinged on the left	-	8612-003
Electric access port	8-pin, for low voltage with LEMO socket (coverable) and LEMO plug (max. 24 V – 2 A)	-	8612-003
Inner door, divided	Cell therapy compartmentalization, consisting of 4 inner doors and two shelf levels with one partition wall each	-	8612-002
O ₂ control range	alternative to the standard range, for controlling O_2 concentrations between 10 and 95 vol. %, only in conjunction with option models with O_2 control	-	8612-0028

^{*} Notes > See last page



ACCESSORIES

Description	*	ArtNo.
the base equipped with casters is used for the secure positioning and leveling of a BINDER CO2 incubator	-	9051-0043
for CO ₂ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose	-	8012-0014
for N ₂ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose	-	8012-0016
for O ₂ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose	-	8012-0015
external, BINDER Gas Supply Service, for connecting 2 gas tanks $(CO_2, N_2 \text{ or } O_2)$, with audible and visual alarms, as well as zero-voltage alarm output	-	8012-0408
Multi Management Software APT-COM™		
version 4, BASIC edition	-	9053-0039
version 4, GLP edition	-	9053-004
version 4, PROFESSIONAL edition	-	9053-0040
concentrated, for gentle remove of residual contaminants; 1 kg	-	1002-0016
IQ/OQ documents – supporting documents for validation performed by customers, consisting of: IQ/OQ checklists incl. calibration guide and comprehensive unit documentation; parameters: temperature, CO ₂ , O ₂ , pressure, depending on unit		
Digital in PDF format	-	7057-0001
Hard copy inside folder	-	7007-000
$IQ/OQ/PQ$ documents – supporting documents for validation performed by customers, according to customer requirements, PQ section added to qualification folder IQ/OQ ; parameters: temperature, CO_2 , O_2 – or pressure, depending on unit		
Digital in PDF format	-	7057-000
Hard copy inside folder	-	7007-000
set anti-slip feet	-	8012-0702
Stainless steel	-	6004-0130
for divided inner door		
stainless steel	-	8012-2058
for the thermally isolated stacking of two BINDER CO ₂ incubators	-	9051-0038
The kit contains a client bridge that establishes a wireless connection between BINDER units and APT-COM4, LIMS, or customer-specific software via an Ethernet interface. It provides an alternative solution in situations where units need to be positioned in locations without an on-site Ethernet connection. In secured networks, installation and configuration must be performed by the customer's IT service.	-	8500-016
	the base equipped with casters is used for the secure positioning and leveling of a BINDER CO ₂ incubator for CO ₃ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose for N ₃ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose for O ₃ , consisting of a gas tank pressure regulator with connection parts and 5-meter hose external, BINDER Gas Supply Service, for connecting 2 gas tanks (CO ₂ , N ₂ or O ₂), with audible and visual alarms, as well as zero-voltage alarm output Multi Management Software APT-COM TM version 4, BASIC edition version 4, GLP edition version 4, FROFESSIONAL edition concentrated, for gentle remove of residual contaminants; 1 kg IQ/OQ documents – supporting documents for validation performed by customers, consisting of: IQ/OQ checklists incl. calibration guide and comprehensive unit documentation; parameters: temperature, CO ₂ , O ₂ , pressure, depending on unit Digital in PDF format Hard copy inside folder IQ/OQ/PQ documents – supporting documents for validation performed by customers, according to customer requirements, PQ section added to qualification folder IQ/OQ; parameters: temperature, CO ₂ , O ₂ – or pressure, depending on unit Digital in PDF format Hard copy inside folder Stainless steel for divided inner door stainless steel for the thermally isolated stacking of two BINDER CO ₂ incubators The kit contains a client bridge that establishes a wireless connection between BINDER units and APT-COM4, LIMS, or customer-specific software via an Ethernet interface. It provides an alternative solution in situations where units need to be positioned in locations without an on-site Ethernet connection. In secured networks, installation and	the base equipped with casters is used for the secure positioning and leveling of a BINDER CO, incubator for CO,, consisting of a gas tank pressure regulator with connection parts and 5-meter hose for N,, consisting of a gas tank pressure regulator with connection parts and 5-meter hose for O,, consisting of a gas tank pressure regulator with connection parts and 5-meter hose cexternal, BINDER Gas Supply Service, for connecting 2 gas tanks (CO ₂ , N ₂ or O ₃), with audible and visual alarms, as well as zero-voltage alarm output Multi Management Software APT-COM TM version 4, BASIC edition version 4, GLP edition version 4, PROFESSIONAL edition concentrated, for gentle remove of residual contaminants; 1 kg IQ/OQ documents - supporting documents for validation performed by customers, consisting of: IQ/OQ checklists incl. calibration guide and comprehensive unit documentation; parameters: temperature, CO ₂ , O ₂ , pressure, depending on unit Digital in PDF format Hard copy inside folder IQ/OQ/PQ documents - supporting documents for validation performed by customers, according to customer requirements, PQ section added to qualification folder IQ/OQ; parameters: temperature, CO ₂ , O ₂ - or pressure, depending on unit Digital in PDF format Hard copy inside folder Stainless steel for divided inner door stainless steel for divided inner door stainless steel for the thermally isolated stacking of two BINDER CO ₂ incubators The kit contains a client bridge that establishes a wireless connection between BINDER units and APT-COM ₄ , LIMS, or customer-specific software via an Ethernet interface. It provides an alternative solution in situations where units need to be positioned in locations without an on-site Ethernet connection. In secured networks, installation and

^{*} Notes > See last page

SERVICES

Designation	Description	*	ArtNo.
Installation services			
Unit installation	Connect the unit to the customer-side connections (electricity, water, wastewater, gas), basic functions check, brief operating instructions. (excl.: unpacking, setup, controller instructions, programming, installation work)	05	DL10-0100
Unit instructions	Instruction regarding operating principle and basic functions of the unit, operation of the control electronics including programming	05	DL10-0500
Maintenance services			
BRONZE 3-year maintenance contract	Maintenance service as contractually agreed, visual inspection of mechanical and electrical components, check of control response, 20% discount on spare parts	05	DL20-0710
GOLD 3-year maintenance contract	Maintenance service as contractually agreed, visual inspection of mechanical and electrical components, check of control response, 20% discount on spare parts, testing of all key functions, replacement of wear parts, calibration of one temperature and CO ₂ value, including certificate	05	DL20-0940
Maintenance	One-off maintenance service in accordance with maintenance schedule. Visual inspection of mechanical and electrical components, testing of all key functions. Calibration of a test temperature specified by the user in center of usable space without certificate	05	DL20-0400
SILVER 3-year maintenance contract	Maintenance service as contractually agreed, visual inspection of mechanical and electrical components, check of control response, 20% discount on spare parts, testing of all key functions, calibration of one test temperature specified by the user in the center of the usable space, without certificate	05	DL20-0820
Calibration services			
CO₂ calibration	${ m CO_2}$ calibration at a specified value, measurements are taken with analyzed test gas at 5%, including certificate	03, 04, 05	DL30-0401
* Notes > See last page			

^{*} Notes > See last page



Designation	Description	*	ArtNo.
O ₂ calibration	$\rm O_2$ calibration with 1 measuring point in center of chamber at a specified $\rm O_2$ percentage value, including certificate	03, 04, 05	DL30-0402
Temperature calibration	Calibration of one (1) test temperature specified by the user in center of chamber, including certificate		DL30-0101
	Extension of calibration of one (1) additional test temperature specified by the user in the center of the usable space, including certificate	03, 04, 05	DL30-0102
Temperature measurement, 18 measuring points	Temperature measurement with 18 measuring points with a set value specified by the user, including certificate	03, 04, 05	DL30-0118
Temperature measurement, 27 measuring points	Temperature measurement with 27 measuring points with a set value specified by the user, including certificate	03, 04, 05	DL30-0127
Temperature measurement, 9 measuring points	Temperature measurement with 9 measuring points with a set value specified by the user, including certificate	03, 04, 05	DL30-0109
Validation services			
Execution of IQ/OQ	Execution of IQ/OQ in accordance with qualification folder	05	DL41-0200
Execution of IQ/OQ/PQ	Execution of IQ/OQ/PQ in accordance with qualification folder	05	DL44-0500
Warranty service			
Warranty extension from 2 to 3 years	The warranty is extended by 1 year from the delivery date, wear parts are excluded	-	DL50-0020

^{*} Notes > See last page



NOTES

- Condensation may occur in the area around the access port. Access ports may be placed in custom locations for an additional charge. UL mark is not granted when this option is used. 01
- 02
- Sensor calibration is performed in an accredited calibration laboratory. 03
- Calibration is performed according to the BINDER factory standard. 04
- Quoted prices do not include travel costs. Please refer to the chapter on BINDER Service for travel costs for your region. Quoted prices for services performed in Switzerland do not include a country-specific added fee (available on request).

BINDER GmbH

Tuttlingen, Germany TEL +49 7462 2005 0 FAX +49 7462 2005 100 info@binder-world.com www.binder-world.com

BINDER Asia Pacific (Hong Kong) Ltd.

Kowloon, Hong Kong, P.R. China TEL +852 39070500 FAX +852 39070507 asia@binder-world.com www.binder-world.com

BINDER Environmental Testing Equipment (Shanghai) Co., Ltd. Shanghai, P.R. China TEL +86 21 685 808 25 FAX +86 21 685 808 29 china@binder-world.com www.binder-world.com

Representative Office for CIS

Moscow, Russia TEL +7 495 988 15 16 FAX +7 495 988 15 17 russia@binder-world.com www.binder-world.com

BINDER Inc. Bohemia, NY, USA TEL +1 631 224 4340 FAX +1 631 224 4354 usa@binder-world.com www.binder-world.us